

Support List for chiptuning and function

动力升级支持列表及其附加功能

TCU 变速箱升级

BOSCH MEVD17

DQ200

DQ250

DQ380

DQ381

DL382

DL501

ZF8HP

T87A

T87

Burbles Activation Module 汽油车放炮

BMW

ME9.2

BOSCH MEVD17

BOSCH MEVD17.2.3

BOSCH MEVD17.2.9

BOSCH MEVD17.2.G

BOSCH MG1CS003.

BOSCH MG1CS201

SIEMENS MSD8X. N54, N53B30 ENGINES ONLY!

SIEMENS MSS54

SIEMENS MSV70

SIEMENS MSV80

Citroën

BOSCH MED17.x

BOSCH MEVD17.4.4

Ford

BOSCH MED9

Honda

BOSCH MED17.9.3

KIA

KEFICO CPEGD2

Mercedes

BOSCH MED17.7.x

BOSCH MED17.7.3.1

BOSCH MED17.7.5

BOSCH MG1X

Mini

BOSCH MEVD17.x

Peugeot

BOSCH MED17.x

BOSCH MEVD17.4.4

Renault

SIEMENS EMS3X10

SIEMENS EMS3110

VAG

BOSCH ME7.1

BOSCH ME7.5

BOSCH ME7.5.10

BOSCH MED9.1

BOSCH MED9.5.10

BOSCH MED17

BOSCH MED17.1

BOSCH MED17.1.1

BOSCH MED17.1.6

BOSCH MED17.5

BOSCH MED17.5.1

BOSCH MED17.5.5

BOSCH MED17.5.21

BOSCH MED17.5.25

BOSCH MG1CS002

BOSCH MG1CS111

SIEMENS SIMOS 10

SIEMENS SIMOS 12

SIEMENS SIMOS 18

Volvo

BOSCH MED9

Popcorn Activation Module 柴油车放炮

BMW

BOSCH EDC16C31 *BETA

BOSCH EDC16C35 *BETA

BOSCH EDC16CP35 *BETA

BOSCH EDC17_C06 *BETA

BOSCH EDC17_C41 *BETA

BOSCH EDC17_C50 *BETA

BOSCH EDC17_C56 *BETA

BOSCH EDC17_C76 *BETA

BOSCH EDC17_CP02 *BETA

BOSCH EDC17_CP09 *BETA

BOSCH EDC17_CP45 *BETA

BOSCH EDC17_CP49 *BETA

Land Rover

MOTOROLA MEMS NNN

VAG

BOSCH EDC15P

BOSCH EDC15V

BOSCH EDC15VM

BOSCH EDC16U1

BOSCH EDC16U31

BOSCH EDC16U34

SIEMENS PCR2.1

EVAP Removal Module (蒸发排放系统故障关闭)

BMW

BOSCH MEVD17.2 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MEVD17.2.2 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MEVD17.2.3 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MEVD17.2.4 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MEVD17.2.5 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MEVD17.2.6 - *IMPORTANT* ACTUATOR PLUG MUST BE

DISCONNECTED!

BOSCH MEVD17.2.8 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MEVD17.2.9 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MEVD17.2.G - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

SIEMENS MSV80 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

SIEMENS MSV81 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

Chevrolet

BOSCH EDC16C39 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

Fiat

BOSCH ME7.3 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

Ford

BOSCH MED17 - *IMPORTANT* ACTUATOR PLUG MUST BE

DISCONNECTED!

Jaguar

BOSCH MED17.0 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.8.3 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.8.31 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.9.7 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

Jeep

MOTOROLA NGC4 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

Land Rover

BOSCH MED17.8.3 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.8.31 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.9.7 - *IMPORTANT* ACTUATOR PLUG MUST BE

DISCONNECTED!

McLaren

BOSCH ME17.8.32 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

Mercedes

BOSCH MED17.7.1 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.7.2 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.7.3 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.7.5 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

PSA

BOSCH MED17.4 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MEV17.4 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.4.2 - *IMPORTANT* ACTUATOR PLUG MUST BE

DISCONNECTED!

BOSCH MED17.4.4 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

Toyota

DENSO - *IMPORTANT* ACTUATOR PLUG MUST BE DISCONNECTED!

VAG

BOSCH MED9.1 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED9.5.10 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.1 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.1.1 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.1.6 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.1.21 - *IMPORTANT* ACTUATOR PLUG MUST BE

DISCONNECTED!

BOSCH MED17.1.27 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.1.61 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.1.62 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.5 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.5.2 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.5.5 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.5.20 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.5.21 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.5.24 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.5.25 - *IMPORTANT* ACTUATOR PLUG MUST BE

DISCONNECTED!

BOSCH MED17.5.26 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.6 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

SIMOS 3 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

SIMOS 8.1 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

SIMOS 8.2 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

SIMOS 8.3 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

SIMOS 8.4 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

SIMOS 8.5 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

SIMOS 8.6 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

SIMOS 10 - *IMPORTANT* ACTUATOR PLUG MUST BE

DISCONNECTED!

SIMOS 11 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

SIMOS 12 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

SIMOS 18 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

Exhaust Flap Removal Module (电子排气阀门移除)

BMW

BOSCH MEVD17.2 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MEVD17.2.2 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MEVD17.2.3 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MEVD17.2.4 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MEVD17.2.5 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MEVD17.2.6 - *IMPORTANT* ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH MEVD17.2.8 - *IMPORTANT* ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH MEVD17.2.9 - *IMPORTANT* ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH MEVD17.2.G - *IMPORTANT* ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH MG1CS003 - *IMPORTANT* ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH MG1CS024 - *IMPORTANT* ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH MG1CS201 - *IMPORTANT* ACTUATOR PLUG MUST BE DISCONNECTED!

SIEMENS MSD80 - *IMPORTANT* ACTUATOR PLUG MUST BE DISCONNECTED!

SIEMENS MSD81 - *IMPORTANT* ACTUATOR PLUG MUST BE DISCONNECTED!

SIEMENS MSD85 - *IMPORTANT* ACTUATOR PLUG MUST BE DISCONNECTED!

SIEMENS MSD87 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

Dacia

BOSCH EDC17_C11 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH EDC17_C42 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH EDC17_C84 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH EDC17_CP19 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH EDC17_CP45 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH EDC17_CP58 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

SIEMENS SID305 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

SIEMENS SID306 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

SIEMENS SID307 - *IMPORTANT* ACTUATOR PLUG MUST BE

DISCONNECTED!

SIEMENS SID309 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

SIEMENS SID310 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

Nissan

BOSCH EDC17_C11 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH EDC17_C42 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH EDC17_C84 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH EDC17_CP19 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH EDC17_CP45 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH EDC17_CP58 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

SIEMENS SID305 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

SIEMENS SID306 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

SIEMENS SID307 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

SIEMENS SID309 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

SIEMENS SID310 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

Porsche

BOSCH ME7.8 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

Renault

BOSCH EDC17_C11 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH EDC17_C42 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH EDC17_C84 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH EDC17_CP19 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH EDC17_CP45 - *IMPORTANT* ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_CP58 - *IMPORTANT* ACTUATOR PLUG MUST BE DISCONNECTED!

SIEMENS SID305 - *IMPORTANT* ACTUATOR PLUG MUST BE DISCONNECTED!

SIEMENS SID306 - *IMPORTANT* ACTUATOR PLUG MUST BE DISCONNECTED!

SIEMENS SID307 - *IMPORTANT* ACTUATOR PLUG MUST BE DISCONNECTED!

SIEMENS SID309 - *IMPORTANT* ACTUATOR PLUG MUST BE DISCONNECTED!

SIEMENS SID310 - *IMPORTANT* ACTUATOR PLUG MUST BE DISCONNECTED!

VAG

BOSCH EDC17_CP04 - *IMPORTANT* ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_CP14 - *IMPORTANT* ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_CP20 - *IMPORTANT* ACTUATOR PLUG MUST BE

DISCONNECTED!

BOSCH EDC17_CP24 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH EDC17_CP44 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH EDC17_CP54 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH EDC17_C46 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH EDC17_C54 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH EDC17C64 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH EDC17C74 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH EDC17CP74 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED9.1 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED9.5.10 - *IMPORTANT* ACTUATOR PLUG MUST BE

DISCONNECTED!

BOSCH MED17 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.1 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.1.1 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.1.6 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.1.21 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.1.27 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.1.61 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.1.62 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.5 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.5.2 - *IMPORTANT* ACTUATOR PLUG MUST BE

DISCONNECTED!

BOSCH MED17.5.5 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.5.20 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.5.21 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.5.24 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.5.25 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.5.26 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

DELPHI DCM6.2 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

SIMOS 10 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

SIMOS 11 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

SIMOS 12 - *IMPORTANT* ACTUATOR PLUG MUST BE

DISCONNECTED!

SIMOS 18 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

Torque Monitoring Disable（扭矩限制关闭）

Alfa Romeo

BOSCH EDC17C49

BOSCH EDC17C69

BMW

BOSCH EDC17_C06

BOSCH EDC17_C41

BOSCH EDC17_C50

BOSCH EDC17_C56

BOSCH EDC17_CP02

BOSCH EDC17_CP09

BOSCH EDC17_CP45

BOSCH EDC17_CP49

SIEMENS MSD80

Chevrolet

BOSCH EDC17_CP18

BOSCH EDC17_CP47

BOSCH EDC17_C59

Chrysler

BOSCH EDC17C49

Citroen

BOSCH EDC17_C10

BOSCH EDC17_CP42

BOSCH MD1CS003

DELPHI DCM 6.2A

Dacia

BOSCH EDC17

FCA (Alfa/Fiat/Lancia)

BOSCH EDC17

Fiat

BOSCH EDC17_C49

BOSCH EDC17_C84

BOSCH EDC17C69

Ford

BOSCH EDC17_C10

BOSCH EDC17C70

DELPHI DCM6.1

SIEMENS SID208

SIEMENS SID209

SIEMENS SID211

Honda

BOSCH EDC17_CP06

BOSCH EDC17_CP16

BOSCH EDC17_CP50

BOSCH EDC17C58

Hyundai

BOSCH EDC17_C08

BOSCH EDC17_C53

BOSCH EDC17_C57

BOSCH EDC17_CP14

Infiniti

DELPHI CRD3

Isuzu

BOSCH EDC17_C83

Iveco

BOSCH EDC17C49

BOSCH EDC17CP52

Jaguar

BOSCH EDC17CP55

Jeep

BOSCH EDC17

BOSCH EDC17_C49

BOSCH EDC17_CP27

BOSCH EDC17_C79

BOSCH EDC17C69

Kia

BOSCH EDC17_C08

BOSCH EDC17_C53

BOSCH EDC17_C57

BOSCH EDC17_CP14

Land Rover

BOSCH EDC17_CP42

BOSCH EDC17CP55

Maserati

BOSCH EDC17_C79

Mercedes

BOSCH EDC17C66

BOSCH EDC17CP10

BOSCH EDC17CP46

BOSCH EDC17CP57

BOSCH MD1CP001 *BETA*

BOSCH MED17.7.2

DELPHI CRD2-651

DELPHI CRD3-651

DELPHI DCM 3.2

DELPHI DCM 3.5

DELPHI CRD1

DELPHI CRD2

DELPHI CRD3 *BETA solution for automatic gearbox

SIEMENS SID310

Mini

BOSCH EDC17C41/C50/CP45

Nissan

BOSCH EDC17_C84

Opel

BOSCH EDC17_C18

BOSCH EDC17_C19

BOSCH EDC17_C59

BOSCH EDC17_C84

BOSCH EDC17_CP47

BOSCH EDC17C49

Peugeot

BOSCH EDC17_C10

BOSCH EDC17_CP42

BOSCH MD1CS003

DELPHI DCM 6.2A

Renault

BOSCH EDC17_C84

SIEMENS SID310

BOSCH ME17.9.20

Suzuki

BOSCH EDC17C49

BOSCH EDC17_C69

Toyota

BOSCH EDC17_CP07

BOSCH EDC17_C73

Volvo

BOSCH EDC17_CP22

BOSCH EDC17_CP48

BOSCH EDC17_CP68

DPF Removal Module（DPF 烟雾颗粒故障关闭）

AEBI Smidth

BOSCH EDC16C39 - COMBINATED SOLUTION.

BOSCH EDC17CP52 - SWITCH SOLUTION.

Alfa Romeo

BOSCH EDC15C2 - COMBINATED SOLUTION.

BOSCH EDC17C49 - COMBINATED SOLUTION. FIRMWARE PATCH.
FULL READOUT REQUIRED. DPF PRESSURE AND TEMPERATURE
SENSORS MUST BE DISCONNECTED!

BOSCH EDC17C69 - SWITCH SOLUTION. DPF PRESSURE AND
TEMPERATURE SENSORS CAN BE DISCONNECTED!

MARELLI MJD6 - SWITCH SOLUTION

MARELLI MJ8D - SWITCH SOLUTION

BMW

BOSCH EDC16C31 - COMBINATED SOLUTION

BOSCH EDC16C35 - COMBINATED SOLUTION

BOSCH EDC16CP35 - COMBINATED SOLUTION

BOSCH EDC17_C06 - SWITCH SOLUTION. DPF PRESSURE AND
TEMPERATURE SENSORS CAN BE DISCONNECTED!

BOSCH EDC17_C41 - SWITCH SOLUTION. DPF PRESSURE AND
TEMPERATURE SENSORS CAN BE DISCONNECTED!

BOSCH EDC17_C50 - SWITCH SOLUTION. DPF PRESSURE AND

TEMPERATURE SENSORS CAN BE DISCONNECTED! IF THE VEHICLE HAS LOW POWER AFTER APPLYING V2, PLEASE USE V1.

BOSCH EDC17_C56 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS CAN BE DISCONNECTED!

BOSCH EDC17_CP02 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS CAN BE DISCONNECTED!

BOSCH EDC17_CP09 - SWITCH SOLUTION. . DPF PRESSURE AND TEMPERATURE SENSORS CAN BE DISCONNECTED!

BOSCH EDC17_CP45 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS CAN BE DISCONNECTED!

BOSCH EDC17C41/C50/C56

BOSCH EDC17_CP49 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS CAN BE DISCONNECTED!

BOSCH MD1CP002 - SWITCH SOLUTION.

BOSCH MD1CS001 - *IMPORTANT* DPF PRESSURE AND EGT SENSORS MUST BE DISCONNECTED!

BOUWMANN

BOSCH EDC16C39 - *IMPORTANT* DPF PRESSURE and EGT sensors CAN be disconnected!

Cadillac

BOSCH EDC17C39 - COMBINATED SOLUTION

Case

BOSCH EDC17C49 - SWITCH SOLUTION

Caterpillar

CAT ADEM5 - COMBINATED SOLUTION. BETA. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

Chevrolet

BOSCH EDC16C39 - EMULATION SOLUTION

BOSCH EDC16CP31

BOSCH EDC16C42 - COMBINATED SOLUTION.

BOSCH EDC17_CP18 - SWITCH SOLUTION. BETA. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17_CP47 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17_C59 - COMBINATED SOLUTION. FIRMWARE PATCH. FULL READOUT REQUIRED. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

DELCO E7x - COMBINATED SOLUTION. IF YOU HAVE SOME ISSUES

PLEASE USE V1 BETA SOLUTION.

DELCO E8x - COMBINATED SOLUTION. IF YOU HAVE SOME ISSUES
PLEASE USE V1 BETA SOLUTION.

DELPHI DCM3.7 - SWITCH SOLUTION

Chrysler

BOSCH EDC16CP31 - EMULATION SOLUTION

BOSCH EDC17C49 - SWITCH SOLUTION. DPF PRESSURE AND
TEMPERATURE SENSORS MUST BE DISCONNECTED!

Citroen

BOSCH EDC15C2

BOSCH EDC16C0 - SWITCH SOLUTION

BOSCH EDC16C3 - SWITCH SOLUTION

BOSCH EDC16C34 - SWITCH SOLUTION

BOSCH EDC16C39 - EMULATION SOLUTION

BOSCH EDC16CP39 - SWITCH SOLUTION

BOSCH EDC17_C60 - SWITCH SOLUTION. DPF PRESSURE AND
TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17_CP11 - SWITCH SOLUTION

BOSCH EDC17_CP42 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17C10 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17CP52 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

DELPHI DCM3.4

DELPHI DCM3.5 - COMBINATED SOLUTION

DELPHI DCM6.2 - COMBINATED SOLUTION

MARELLI MJ8D - SWITCH SOLUTION

MARELLI MJ8DF2

MARELLI MJ8DF3

SIEMENS SID208 - COMBINATED SOLUTION

SIEMENS SID803 - COMBINATED SOLUTION

SIEMENS SID803A - COMBINATED SOLUTION

SIEMENS SID807 - COMBINATED SOLUTION

Dacia

BOSCH EDC17_C42 - COMBINATED SOLUTION. DPF PRESSURE AND

TEMPERATURE SENSORS MUST BE DISCONNECTED! FULL READ
REQUIRED!

DELPHI DCM3.4 - COMBINATED SOLUTION

SIEMENS SID305 - COMBINATED SOLUTION

SIEMENS SID306 - COMBINATED SOLUTION

SIEMENS SID310 - COMBINATED SOLUTION

Dodge

BOSCH EDC16CP31 - COMBINATED SOLUTION. DPF PRESSURE AND
TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC16U31 - COMBINATED SOLUTION

BOSCH EDC16U34 - SWITCH SOLUTION

BOSCH EDC17_C79 - SWITCH SOLUTION. DPF PRESSURE AND
TEMPERATURE SENSORS CAN BE DISCONNECTED!

CUMMINS CM21XX - COMBINATED SOLUTION. DPF PRESSURE AND
TEMPERATURE SENSORS MUST BE DISCONNECTED!

Doosan

BOSCH EDC17CV41 - COMBINATED SOLUTION

FCA (Alfa/Fiat/Lancia)

BOSCH EDC15C2

BOSCH EDC16C39

BOSCH EDC17C49

BOSCH EDC17C69

BOSCH EDC17CP27

DELPHI DCM 3.5

MARELLI MJ8DF2

MARELLI MJ8DF3

MARELLI MJD6F3

Honda

BOSCH EDC16C31

BOSCH EDC17CP06/16

Hyundai

BOSCH EDC16C39

BOSCH EDC17C08

BOSCH EDC17C08/CP14

BOSCH EDC17C53

BOSCH EDC17C57

Iveco

BOSCH EDC16C39

BOSCH EDC17C49

BOSCH EDC17C69

BOSCH EDC17CP52

Jaguar

SIEMENS SID204

Jeep

BOSCH EDC16CP31

BOSCH EDC16U31

BOSCH EDC17C69

BOSCH EDC17CP27

DELPHI CRD2-651

Kia

BOSCH EDC16C39

BOSCH EDC17C08/CP14

BOSCH EDC17C57

Land Rover

BOSCH EDC16CP39

BOSCH EDC17CP11

BOSCH EDC17CP42

BOSCH MEDC17.9

Mahindra

BOSCH EDC17C53

Mazda

BOSCH EDC16C34

DENSO R2AX

DENSO RF7x/RF8x

DENSO SH1/12/13/14

Mercedes

BOSCH EDC16C2

BOSCH EDC16C31

BOSCH EDC16C32

BOSCH EDC16CP36

BOSCH EDC17C43

BOSCH EDC17CP10

BOSCH EDC17CP46

DELPHI CRD2-651

DELPHI CRD3-651

DELPHI DCM 3.2

Mini

BOSCH EDC16C35

BOSCH EDC17C41

BOSCH EDC17C50

Mitsubishi

DENSO 4N13/14

Nissan

BOSCH EDC16C36

BOSCH EDC16CP33

BOSCH EDC17C42

DELPHI DCM 3.4

DENSO SH7058

SIEMENS SID301

SIEMENS SID305

SIEMENS SID307

Opel

BOSCH EDC16C36

BOSCH EDC16C9/C39

BOSCH EDC17C18/C19

BOSCH EDC17C42

BOSCH EDC17C59

DELCO E87

DELPHI DCM 3.7

DENSO SH7058/59

MARELLI MJD6

Peugeot

BOSCH EDC15C2

BOSCH EDC16C34

BOSCH EDC16CP39

BOSCH EDC17C10

BOSCH EDC17C60

BOSCH EDC17CP52

DELPHI DCM 3.4

DELPHI DCM 3.5

MARELLI MJ8DF2

MARELLI MJ8DF3

SIEMENS SID208

SIEMENS SID803

SIEMENS SID803A

SIEMENS SID807

Piaggio

BOSCH EDC17C08

Porsche

BOSCH EDC17CP14/CP44

Renault

BOSCH EDC16C3

BOSCH EDC16C36

BOSCH EDC16CP33

BOSCH EDC17C42

DELPHI DCM 3.4

SIEMENS SID301

SIEMENS SID305

SIEMENS SID307

Saab

BOSCH EDC16C9/C39

Smart

BOSCH EDC16C32

Subaru

DENSO SH7058/59

Suzuki

BOSCH EDC16C3

MARELLI MJ8DS3

Toyota

BOSCH EDC17C73

BOSCH EDC17CP07

DENSO (2.0D-4D/2.2D-4D)

VAG (Audi/Seat/Skoda/Volkswagen)

BOSCH EDC16CP34

BOSCH EDC16U31/U34

BOSCH EDC17C64

BOSCH EDC17CP04/CP14/CP20/CP44/C46/C54/U1

DELPHI DCM 3.7

DELPHI DCM 6.2V

SIEMENS PCR2.1

SIEMENS PPD

Volvo

BOSCH EDC16C31

BOSCH EDC16C34

SIEMENS SID803

SIEMENS SID803A

SIEMENS SID807EVO

SIEMENS SID803A

Fiat

BOSCH EDC16C39 - COMBINATED SOLUTION. TEMPERATURE
SENSORS MUST BE DISCONNECTED! (For Ducato, DPF Pressure

sensor must also be disconnected!) BDM READ REQUIRED.

BOSCH EDC17C69 - SWITCH SOLUTION. - *IMPORTANT* DPF PRESSURE and EGT sensors have be disconnected!

BOSCH EDC17_C10 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17_C49 - SWITCH SOLUTION. FULL READ REQUIRED. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17CP52 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

DELPHI DCM3.5 - COMBINATED SOLUTION

MARELLI MJD6 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS CAN BE DISCONNECTED!

MARELLI MJ8D - SWITCH SOLUTION

MARELLI MJ8F - SWITCH SOLUTION

MARELLI MJ9D - SWITCH SOLUTION

SIEMENS SID803 - COMBINATED SOLUTION

SIEMENS SID803A - COMBINATED SOLUTION

VISTEON DCU10x - COMBINATED SOLUTION

Ford

BOSCH EDC16C34 - SWITCH SOLUTION. DISCONNECT UREA ECU PLUG.

BOSCH EDC16CP39 - COMBINATED SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17_C10 - COMBINATED SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17C70

BOSCH EDC17_CP05 - COMBINATED SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17_CP42 - COMBINATED SOLUTION

BOSCH EDC17C70 - COMBINATED SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

DELPHI DCM3.5 - COMBINATED SOLUTION

DELPHI DCM6.1 - COMBINATED SOLUTION

DELPHI MPC555 - COMBINATED SOLUTION. DPF PRESSURE SENSOR CAN BE DISCONNECTED. BETA. FULL READ REQUIRED (MPC AND FLS)

MARELLI MJD6 - SWITCH SOLUTION

MARELLI MJ8D - SWITCH SOLUTION

SIEMENS SID206 - COMBINATED SOLUTION

SIEMENS SID208 - COMBINATED SOLUTION

SIEMENS SID209 - COMBINATED SOLUTION. DPF PRESSURE AND
TEMPERATURE SENSORS MUST BE DISCONNECTED!

SIEMENS SID211 - COMBINATED SOLUTION

SIEMENS SID803 - COMBINATED SOLUTION

SIEMENS SID803A - COMBINATED SOLUTION

SIEMENS SID807 - COMBINATED SOLUTION

VISTEON DCU102 - SWITCH SOLUTION. DPF PRESSURE AND
TEMPERATURE SENSORS MUST BE DISCONNECTED!

VISTEON DCU106 - COMBINATED SOLUTION. DPF PRESSURE AND
TEMPERATURE SENSORS MUST BE DISCONNECTED!

VISTEON DCU201 - COMBINATED SOLUTION

HINO

DENSO SH7058 - COMBINATED SOLUTION

Holden

DELCO E98 - COMBINATED SOLUTION

Honda

BOSCH EDC16C31 - COMBINATED SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED! SEND ORIGINAL FILE THROUGH TICKET SYSTEM.

BOSCH EDC17_CP06 - SWITCH SOLUTION (USE V1 IF YOU EXPERIENCE LIMP OR CRUISE CONTROL NOT WORKING)

BOSCH EDC17_CP16 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17_CP50 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS CAN BE DISCONNECTED!

BOSCH EDC17C58 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

Hyundai

BOSCH EDC16C39 - SWITCH SOLUTION. FULL READ REQUIRED FOR AUTOMATIC GEARBOX CARS. TEMPERATURE SENSORS CAN BE DISCONNECTED!

BOSCH EDC17_C08 - SWITCH SOLUTION

BOSCH EDC17_CP14 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17_C53 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17_C57 - SWITCH SOLUTION

CUMMINS CM2250 - COMBINATED SOLUTION

DELPHI DCM3.7 - COMBINATED SOLUTION

DELPHI DCM6.2A - COMBINATED SOLUTION

Great Wall

DELPHI DCM3.7 - COMBINATED SOLUTION

International

BOSCH EDC17CV42 - COMBINATED SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

SIEMENS SID904 - COMBINATED SOLUTION.

Infiniti

BOSCH EDC16CP42 - COMBINATED SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

DELPHI CRD3 - COMBINATED SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

Iveco

BOSCH EDC16C39 - COMBINATED SOLUTION

BOSCH EDC17C49 - SWITCH SOLUTION. DPF PRESSURE AND

TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17C69 - SWITCH SOLUTION. DPF PRESSURE AND
TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17CP52 - SWITCH SOLUTION. DPF PRESSURE AND
TEMPERATURE SENSORS CAN BE DISCONNECTED!

BOSCH EDC17CV41 - SWITCH SOLUTION

Isuzu

BOSCH EDC17_C83

BOSCH EDC17CV41 - COMBINATED SOLUTION. DPF PRESSURE AND
TEMPERATURE SENSORS MUST BE DISCONNECTED!

DENSO - COMBINATED SOLUTION.

TRANSTRON - COMBINATED SOLUTION.

JAC

BOSCH EDC17_C53

Jaguar

BOSCH EDC17_CP11 - SWITCH SOLUTION. DPF PRESSURE AND
TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17_CP42 - SWITCH SOLUTION. DPF PRESSURE AND
TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17CP55 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH MEDC17.9 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

DELPHI MPC555 - COMBINATED SOLUTION. BETA.

SIEMENS SID201 - COMBINATED SOLUTION

SIEMENS SID204 - COMBINATED SOLUTION

JCA

BOSCH EDC16C39 - COMBINATED SOLUTION

Jeep

BOSCH EDC16U34 - SWITCH SOLUTION

BOSCH EDC16CP31- SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17C49 - SWITCH SOLUTION. FULL READ REQUIRED. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17C69 - SWITCH SOLUTION. DPF PRESSURE SENSOR CAN BE DISCONNECTED!

BOSCH EDC17_C79 - SWITCH SOLUTION. DPF PRESSURE SENSOR CAN BE DISCONNECTED!

BOSCH EDC17_CP27 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

DELPHI CRD2.x - COMBINATED SOLUTION

JINBEI

BOSCH EDC17_C81 - SWITCH SOLUTION. DPF PRESSURE AND EGT SENSORS CAN BE DISCONNECTED!

JMC

BOSCH EDC17_C63 - SWITCH SOLUTION. DPF PRESSURE AND EGT SENSORS CAN BE DISCONNECTED!

BOSCH EDC17_C81 - SWITCH SOLUTION. DPF PRESSURE AND EGT SENSORS CAN BE DISCONNECTED!

John Deere

PHOENIX Lxx - COMBINATED SOLUTION. BETA.

Kenworth

CAT ADEM4 - COMBINATED SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

Kia

BOSCH EDC16C39 - SWITCH SOLUTION. BDM READ REQUIRED. DPF TEMPERATURE SENSORS CAN BE DISCONNECTED!

BOSCH EDC17_C08 - SWITCH SOLUTION

BOSCH EDC17_C53 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17_C57

BOSCH EDC17_CP14 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

DELPHI DCM3.2 - COMBINATED SOLUTION

DELPHI DCM3.7 - COMBINATED SOLUTION

DELPHI DCM6.2A - COMBINATED SOLUTION

Kioti

DELPHI DCM3.7 - COMBINATED SOLUTION

Kubota

DENSO - COMBINATED SOLUTION

Lancia

BOSCH EDC15C2 - COMBINATED SOLUTION.

BOSCH EDC17_C49 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17_CP27 - SWITCH SOLUTION

MARELLI MJD6 - SWITCH SOLUTION

MARELLI MJ8D - SWITCH SOLUTION

MARELLI MJ9D - SWITCH SOLUTION

Land Rover

BOSCH EDC16CP39 - COMBINATED SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17CP55 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17_CP11 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17_CP42 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH MEDC17.9 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

SIEMENS SID201 - COMBINATED SOLUTION

SIEMENS SID204 - COMBINATED SOLUTION

SIEMENS SID208 - COMBINATED SOLUTION

LDV

BOSCH EDC1639 - COMBINATED SOLUTION

BOSCH EDC17_C81 - SWITCH SOLUTION. DPF PRESSURE AND EGT SENSORS CAN BE DISCONNECTED!

LTI

BOSCH EDC16C39 - COMBINATED SOLUTION

Lexus

DENSO (Disconnect 5th injector plug)

Mahindra

BOSCH EDC17_C53 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17_C63 - SWITCH SOLUTION. DPF PRESSURE AND EGT SENSORS CAN BE DISCONNECTED!

BOSCH EDC17_C81 - SWITCH SOLUTION. DPF PRESSURE AND EGT SENSORS CAN BE DISCONNECTED!

MAN

BOSCH EDC17CV41 - *IMPORTANT* DPF PRESSURE AND EGT SENSORS MUST BE DISCONNECTED!

Manitou

BOSCH EDC17C49 - SWITCH SOLUTION.

Maserati

BOSCH EDC17_C79 - SWITCH SOLUTION.

Mazda

BOSCH EDC16C34 - SWITCH SOLUTION

DENSO - COMBINATED SOLUTION. RF7 , RF8, SH1, R2A, SH12

SIEMENS SID208 - COMBINATED SOLUTION

SIEMENS SID807 - COMBINATED SOLUTION

Maxus

BOSCH EDC17_C53 - SWITCH SOLUTION

BOSCH EDC17_C81 - SWITCH SOLUTION. DPF PRESSURE AND EGT
SENSORS CAN BE DISCONNECTED!

Mercedes

BOSCH EDC16C31 - COMBINATED SOLUTION. BDM READ REQUIRED.
DPF PRESSURE AND TEMPERATURE SENSORS MUST BE
DISCONNECTED!

BOSCH EDC16C32 - COMBINATED SOLUTION. BDM READ REQUIRED.
DPF PRESSURE AND TEMPERATURE SENSORS MUST BE
DISCONNECTED!

BOSCH EDC16CP31 - COMBINATED SOLUTION. BDM READ
REQUIRED. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE

DISCONNECTED!

BOSCH EDC16CP36 - COMBINATED SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17_C42 - COMBINATED SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED! FULL READ REQUIRED!

BOSCH EDC17C43 - SWITCH BETA SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17C66 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS CAN BE DISCONNECTED

BOSCH EDC17CP01 - SWITCH SOLUTION

BOSCH EDC17CP10 - SWITCH BETA SOLUTION. SOLUTION MUST BE APPLIED TO IROM ONLY. DPF PRESSURE AND TEMPERATURE SENSORS CAN BE DISCONNECTED!

BOSCH EDC17CP46 - SWITCH BETA SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS CAN BE DISCONNECTED!

BOSCH EDC17CP57 - COMBINATED SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED! BETA SOLUTION.

DELPHI CRD1.x (DCM3.2) - COMBINATED SOLUTION

(PROCESSOR/MPC ELEMENT REQUIRED). DPF PRESSURE AND 2nd
EXHAUST TEMPERATURE SENSORS MUST BE DISCONNECTED!

DELPHI CRD2.x (DCM3.5) - COMBINATED SOLUTION

DELPHI CRD3 - COMBINATED SOLUTION.

DELPHI CRD3.X - COMBINATED SOLUTION. DPF PRESSURE AND
TEMPERATURE SENSORS MUST BE DISCONNECTED! BETA
SOLUTION.

SIEMENS SID307 - COMBINATED SOLUTION.

SIEMENS SID310 - COMBINATED SOLUTION.

Mercedes Truck

TEMIC ACM / MCM - COMBINATED SOLUTION. SOLUTION MUST BE
APPLIED TO BOTH ACM AND MCM UNITS.

Mini

BOSCH EDC16C35 - SWITCH SOLUTION

BOSCH EDC17_C41 - SWITCH SOLUTION. DPF PRESSURE AND
TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17_C50 - SWITCH SOLUTION. DPF PRESSURE AND
TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17_C56 - SWITCH SOLUTION. DPF PRESSURE AND

TEMPERATURE SENSORS MUST BE DISCONNECTED!

Mitsubishi

BOSCH EDC16C3 - COMBINATED SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC16C31 - COMBINATED SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED! FULL READ REQUIRED!

BOSCH EDC16U31 - COMBINATED SOLUTION FULL READ REQUIRED!

BOSCH EDC17C49 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17CP15 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS CAN BE DISCONNECTED!

BOSCH EDC17CP52- SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

DENSO - COMBINATED SOLUTION.

DENSO RA6 - COMBINATED SOLUTION.

DENSO 6M60 - COMBINATED SOUTION.

SIEMENS SID807 - COMBINATED SOLUTION.

New Holland

BOSCH EDC17C49 - SWITCH SOLUTION.

BOSCH EDC17CV41 - SWITCH SOLUTION.

Nissan

BOSCH EDC16CP33 - COMBINATED SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC16CP42 - COMBINATED SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17_C42 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED! FULL READ REQUIRED!

BOSCH EDC17_C84 - COMBINATED SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

DELPHI DCM3.4 - COMBINATED SOLUTION.

DENSO - COMBINATED SOLUTION.

DENSO SH06 - COMBINATED SOLUTION.

SIEMENS SID301 - COMBINATED SOLUTION.

SIEMENS SID304 - COMBINATED SOLUTION.

SIEMENS SID305 - COMBINATED SOLUTION.

SIEMENS SID307 - COMBINATED SOLUTION.

SIEMENS SID309 - COMBINATED SOLUTION.

SIEMENS SID310 - COMBINATED SOLUTION.

Opel

BOSCH EDC16C36 - COMBINATED SOLUTION.

BOSCH EDC16C39 - SWITCH SOLUTION. BETA.

BOSCH EDC16CP33 - COMBINATED SOLUTION.

BOSCH EDC17_C11 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17_C18 - FIRMWARE PATCH. FULL READOUT REQUIRED. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17_C19 - FIRMWARE PATCH. FULL READOUT REQUIRED. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17_C42 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED! FULL READ REQUIRED!

BOSCH EDC17C69 - *IMPORTANT* DPF PRESSURE AND EGT SENSORS MUST BE DISCONNECTED!

BOSCH EDC17_C84 - SWITCH SOLUTION. DPF PRESSURE SENSOR MUST BE DISCONNECTED!

BOSCH EDC17C49 - FIRMWARE PATCH. FULL READOUT REQUIRED. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17_CP47 - COMBINATED SOLUTION. FULL READOUT REQUIRED. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17_C59 - FIRMWARE PATCH. FULL READOUT REQUIRED. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

DELCO E7x - COMBINATED SOLUTION. IF YOU HAVE SOME ISSUES, PLEASE USE V1 BETA SOLUTION.

DELCO E8x - COMBINATED SOLUTION. IF YOU HAVE SOME ISSUES, PLEASE USE V1 BETA SOLUTION.

DELCO E98 - COMBINATED SOLUTION. BETA.

DELPHI DCM3.7 - SWITCH SOLUTION.

DENSO - COMBINATED SOLUTION. ONLY FOR 1.7 DTR (110 HP AND 125 HP) AND 3.0 CDTI(BETA) ENGINES * ON 1MEGA ECUS DASH ECU NEEDS TO BE PROGRAMED AS NON DPF DASH (OPCOM).

MARELLI MJD6 - SWITCH SOLUTION.

SIEMENS SID309 - COMBINATED SOLUTION.

Peugeot

BOSCH EDC16C0 - SWITCH SOLUTION.

BOSCH EDC16C3 - SWITCH SOLUTION.

BOSCH EDC16C34 - SWITCH SOLUTION.

BOSCH EDC16C39 - EMULATION SOLUTION.

BOSCH EDC16CP39 - SWITCH SOLUTION.

BOSCH EDC17_C60 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17_CP11 - SWITCH SOLUTION.

BOSCH EDC17_CP42 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17C10 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17CP52 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

DELPHI DCM3.5 - COMBINATED SOLUTION.

DELPHI DCM6.2 - COMBINATED SOLUTION.

SIEMENS SID201 - COMBINATED SOLUTION.

SIEMENS SID208 - COMBINATED SOLUTION.

SIEMENS SID803 - COMBINATED SOLUTION.

SIEMENS SID803A - COMBINATED SOLUTION.

SIEMENS SID807 - COMBINATED SOLUTION.

Piaggio

BOSCH EDC17_C08 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS CAN BE DISCONNECTED!

Porsche

BOSCH EDC17_CP14 - SWITCH SOLUTION.

BOSCH EDC17_CP44 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

Renault

BOSCH EDC16C3 - COMBINATED SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC16C36 - COMBINATED SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC16CP33 - COMBINATED SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17_C11 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17_C42 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED! FULL READ REQUIRED!

BOSCH EDC17_C84 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS CAN BE DISCONNECTED!

BOSCH EDC17_CP19 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS CAN BE DISCONNECTED!

BOSCH EDC17_CP58 - COMBINATED SOLUTION.

DELPHI DCM3.4 - COMBINATED SOLUTION.

SIEMENS SID301 - COMBINATED SOLUTION.

SIEMENS SID303 - COMBINATED SOLUTION.

SIEMENS SID304 - COMBINATED SOLUTION.

SIEMENS SID305 - COMBINATED SOLUTION.

SIEMENS SID307 - COMBINATED SOLUTION.

SIEMENS SID309 - COMBINATED SOLUTION.

SIEMENS SID310 - COMBINATED SOLUTION.

Saab

BOSCH EDC17_CP21 - COMBINATED SOLUTION. FIRMWARE PATCH.
FULL READOUT REQUIRED.

Smart

BOSCH EDC16C31 - COMBINATED SOLUTION. BDM READ
REQUIRED!

Ssang Yong

DELPHI DCM3.2 - COMBINATED SOLUTION.

Subaru

BOSCH EDC17_CP07 - COMBINATED SOLUTION.

DENSO - COMBINATED SOLUTION.

Suzuki

BOSCH EDC16C3 - COMBINATED SOLUTION. DPF PRESSURE AND
TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC16C39 - COMBINATED SOLUTION. DPF PRESSURE AND
TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17_C49 - SWITCH SOLUTION. FULL READ REQUIRED. DPF
PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17_C69 - COMBINATED SOLUTION. FULL READ REQUIRED. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

MARELLI MJ8X - COMBINATED SOLUTION.

Tata

DELPHI DCM3.4 - COMBINATED SOLUTION.

DELPHI DCM3.7 - COMBINATED SOLUTION.

Tata Trucks

BOSCH EDC17CV54 - SWITCH SOLUTION.

Tigercat

CUMMINS CM2250 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS CAN BE DISCONNECTED!

Toyota

BOSCH EDC16C34 - COMBINATED SOLUTION.

BOSCH EDC17_CP07 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS CAN BE DISCONNECTED!

BOSCH EDC17_C73 - SWITCH SOLUTION.

DENSO (DISCONNECT 5TH INJECTOR PLUG INSTALL 1 KOHM RESISTOR). FOR ENGINES 3.0 AND ABOVE USE V1 SOLUTION.

VAG

BOSCH EDC16U1 - SWITCH SOLUTION.

BOSCH EDC16U31 - SWITCH SOLUTION.

BOSCH EDC16U34 - SWITCH SOLUTION.

BOSCH EDC16CP34 - SWITCH SOLUTION. TEMPERATURE SENSORS
MUST BE DISCONNECTED!

BOSCH EDC17_U01 - SWITCH SOLUTION. TEMPERATURE SENSORS
CAN BE DISCONNECTED!

BOSCH EDC17_U05 - SWITCH SOLUTION.

BOSCH EDC17_CP04 - SWITCH SOLUTION. DPF PRESSURE AND
TEMPERATURE SENSORS CAN BE DISCONNECTED!

BOSCH EDC17_CP14 - SWITCH SOLUTION. DPF PRESSURE AND
TEMPERATURE SENSORS CAN BE DISCONNECTED!

BOSCH EDC17_CP20 - SWITCH SOLUTION. DPF PRESSURE AND
TEMPERATURE SENSORS CAN BE DISCONNECTED!

BOSCH EDC17_CP24 - SWITCH SOLUTION. DPF PRESSURE AND
TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17_CP44 - SWITCH SOLUTION. DPF PRESSURE AND
TEMPERATURE SENSORS CAN BE DISCONNECTED!

BOSCH EDC17_CP54 - SWITCH SOLUTION.

BOSCH EDC17_C46 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS CAN BE DISCONNECTED!

BOSCH EDC17_C54 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS CAN BE DISCONNECTED!

BOSCH EDC17C64 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS CAN BE DISCONNECTED!

BOSCH EDC17C74 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17CP74 - SWITCH SOLUTION.

DELPHI DCM3.7 - COMBINATED SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS CAN BE DISCONNECTED!

DELPHI DCM6.2 - COMBINATED SOLUTION. BETA.

SIEMENS PCR2.1 - COMBINATED SOLUTION.

Volvo

BOSCH EDC16C31 - SWITCH SOLUTION.

BOSCH EDC16C34 - SWITCH SOLUTION.

BOSCH EDC17_CP22 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS MUST BE DISCONNECTED!

BOSCH EDC17_CP48 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS CAN BE DISCONNECTED!

BOSCH EDC17_CP68 - SWITCH SOLUTION. DPF PRESSURE AND TEMPERATURE SENSORS CAN BE DISCONNECTED!

SIEMENS SID206 - COMBINATED SOLUTION.

SIEMENS SID803A - COMBINATED SOLUTION.

SIEMENS SID807 - COMBINATED SOLUTION.

DENSO VEA -

Volvo Trucks

TRW EMS2 - COMBINATED SOLUTION. DPF PRESSURE AND AFTERTREATMENT ECU MUST BE DISCONNECTED.

Example of cars covered by DPF Removal Module v1.0:

Alfa Romeo - Bosch EDC15/EDC16/EDC17

Audi - Bosch EDC16/EDC17, Siemens PPD

BMW - Bosch EDC16/EDC17

Citroen - Bosch EDC15/EDC16, Siemens SID, Delphi DCM3.x

Chevrolet - Bosch EDC16/EDC17

Chrysler - Bosch EDC16CP31

Fiat - Bosch EDC15/EDC16/EDC17, Marelli MJD

Ford - Bosch EDC16/EDC17, Siemens SID

Honda - Bosch EDC16/EDC17, Siemens SID

Hyundai - Bosch EDC16/EDC17

Iveco - Bosch EDC16

Jaguar - Bosch EDC16/EDC17

Kia - Bosch EDC16/EDC17

Lancia - Bosch EDC15/EDC16/EDC17

Mini - Bosch EDC16/EDC17

Mazda - Bosch EDC16/EDC17, Denso (HARD RESET)

Mercedes - Bosch EDC16/EDC17

Nissan - Bosch EDC16, Denso (BETA)

Opel - Bosch EDC16/EDC17, Marelli MJD

Peugeot - Bosch EDC15/EDC16, Siemens SID, Delphi DCM3.x

Porsche - Bosch EDC17

Renault - Bosch EDC16

Saab - Bosch EDC16/EDC17

Seat - Bosch EDC16/EDC17, Siemens PPD

Skoda - Bosch EDC16/EDC17, Siemens PPD

Suzuki - Bosch EDC16

Toyota - Bosch EDC17

Volvo - Bosch EDC16/EDC17, Siemens SID

VW - Bosch EDC16/EDC17, Siemens PPD

EGR Removal Module (EGR 废气阀关闭)

AEBI SCHMIDT

BOSCH EDC16C39

Alfa Romeo

BOSCH EDC15C7 (EGR Actuator plug must be disconnected)

BOSCH EDC16C8 (EGR Actuator plug must be disconnected)

BOSCH EDC16C39 (EGR Actuator plug must be disconnected)

BOSCH EDC17_C49 (EGR Actuator plug must be disconnected)

BOSCH EDC17C69

BMW

BOSCH EDC15C2/C4

BOSCH EDC15M

BOSCH EDC15C4 (EGR Actuator plug can be disconnected)

BOSCH EDC16C31

BOSCH EDC16C35

BOSCH EDC16CP35

BOSCH EDC17_C06 (EGR Actuator plug must be disconnected)

BOSCH EDC17_C41 (EGR Actuator plug must be disconnected)

BOSCH EDC17_C50 (EGR Actuator plug must be disconnected)

BOSCH EDC17_C56

BOSCH EDC17_C76 (EGR Actuator plug must be disconnected)

BOSCH EDC17_CP02 (EGR Actuator plug must be disconnected)

BOSCH EDC17_CP09 (EGR Actuator plug can be disconnected)

BOSCH EDC17_CP45 (EGR Actuator plug can be disconnected)

BOSCH EDC17_CP49 (EGR Actuator plug can be disconnected)

BOSCH MD1CP002

BOSCH MDG1_MD1CS001

Case

BOSCH EDC17C49 (EGR Actuator plug must be disconnected)

Caterpillar

CAT ADEM5 (EGR Actuator plug must be disconnected)

CAT A5M8

Chevrolet

BOSCH EDC16C39

BOSCH EDC17_CP47 (EGR Actuator plug can be disconnected)

DELCO E83 (EGR Actuator plug can be disconnected)

DELCO E87 (EGR Actuator plug can be disconnected)

DELCO E98 (EGR Actuator plug can be disconnected)

DELPHI DCM3.7 (EGR Actuator plug must be disconnected)

Chrysler

BOSCH EDC15C2 (EGR Actuator plug must be disconnected)

BOSCH EDC15C5

BOSCH EDC15C7 (EGR Actuator plug must be disconnected)

BOSCH EDC16C31 (EGR Actuator plug must be disconnected)

BOSCH EDC16U31 (EGR Actuator plug must be disconnected)

Citroen

BOSCH EDC15C2 (EGR Actuator plug must be disconnected)

BOSCH EDC15C3 (EGR Actuator plug must be disconnected)

BOSCH EDC16C0

BOSCH EDC16C7

BOSCH EDC16C34 (EGR Actuator plug must be disconnected)

BOSCH EDC16C39

BOSCH EDC16CP39 (EGR Actuator plug must be disconnected)

BOSCH EDC17_CP11 (EGR Actuator plug must be disconnected)

BOSCH EDC17C10 (EGR Actuator plug must be disconnected)

BOSCH EDC17C60 (EGR Actuator plug must be disconnected)

BOSCH EDC17_CP42

BOSCH EDC17CP52 (EGR Actuator plug must be disconnected)

DELPHI (1.4HDI)

DELPHI DCM3.4

DELPHI DCM3.5

DELPHI DCM6.2 (EGR Actuator plug must be disconnected)

DELPHI DDCR (EGR Actuator plug must be disconnected)

MARELLI MJD6

MARELLI MJ8DF2

MARELLI MJ8DF3

SIEMENS SID201 (EGR Actuator plug must be disconnected)

SIEMENS SID208

SIEMENS SID801

SIEMENS SID802

SIEMENS SID803

SIEMENS SID803A

SIEMENS SID804 (EGR Actuator plug must be disconnected)

SIEMENS SID805 (EGR Actuator plug must be disconnected)

SIEMENS SID806 (EGR Actuator plug must be disconnected)

SIEMENS SID807 (EGR Actuator plug must be disconnected)

VISTEON DCU102

VISTEON DCU10x

SAGEM S2

Dacia

BOSCH EDC17_C42 (EGR Actuator plug must be disconnected)

BOSCH EDC17_C84 (EGR Actuator plug must be disconnected)

DELPHI DCM3.4 (EGR Actuator plug must be disconnected)

DELPHI DDCR (EGR Actuator plug must be disconnected)

SIEMENS SID301 (EGR Actuator plug can be disconnected)

SIEMENS SID303 (EGR Actuator plug can be disconnected)

SIEMENS SID305 (EGR Actuator plug can be disconnected)

SIEMENS SID306 (EGR Actuator plug can be disconnected)

SIEMENS SID307 (EGR Actuator plug can be disconnected)

SIEMENS SID309 (EGR Actuator plug can be disconnected)

SIEMENS SID310 (EGR Actuator plug can be disconnected)

FCA (Alfa/Fiat/Lancia)

Dodge

BOSCH EDC16CP31

BOSCH EDC16U31 (EGR Actuator plug must be disconnected)

BOSCH EDC17_C79

CUMMINS CM21XX (EGR Actuator plug must be disconnected)

Doosan

BOSCH EDC17CV41 (EGR Actuator plug must be disconnected)

Fendt

BOSCH EDC7UC31

Fiat

BOSCH EDC15C2 (EGR Actuator plug must be disconnected)

BOSCH EDC15C7 (EGR Actuator plug must be disconnected)

BOSCH EDC16C8

BOSCH EDC16C9 BDM READ REQUIRED.

BOSCH EDC16C39 BDM READ REQUIRED.

BOSCH EDC17_C49

BOSCH EDC17C69 (EGR Actuator plug can be disconnected)

BOSCH EDC17CP52 (EGR Actuator plug can be disconnected)

DELPHI DCM3.5

MARELLI MJD6

MARELLI MJ8 (with 1.3 MJ only)

MARELLI MJ9

SIEMENS SID803

SIEMENS SID803A

VISTEON DCU102

VISTEON DCU104

Ford

MARELLI IAW 5SF HW401/403/413

MARELLI MJ8DF2

MARELLI MJ8DF3

BOSCH EDC16C3 (EGR Actuator plug must be disconnected)

BOSCH EDC16C7 (EGR Actuator plug must be disconnected)

BOSCH EDC16C34 (EGR Actuator plug must be disconnected)

BOSCH EDC16CP39 (EGR Actuator plug must be disconnected)

BOSCH EDC17_C10

BOSCH EDC17C70 (EGR Actuator plug must be disconnected)

BOSCH EDC17_CP05

BOSCH EDC17_CP65 - ***IMPORTANT*** ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH EDC17_CP42

DELPHI DCM3.4

DELPHI DCM3.5

DELPHI DCM6.1

DELPHI MPC555. (EGR Actuator plug must be disconnected)

SIEMENS SID206/202

SIEMENS SID208

SIEMENS SID209

SIEMENS SID211 (EGR Actuator plug must be disconnected)

SIEMENS SID802 (EGR Actuator plug must be disconnected)

SIEMENS SID803

SIEMENS SID803A

SIEMENS SID807

SIEMENS SID804 (EGR Actuator plug must be disconnected)

SIEMENS SID807EVO

VISTEON DCU10x

VISTEON DCU101

VISTEON DCU102

VISTEON DCU201 (EGR Actuator plug must be disconnected)

VISTEON EECVI - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MD1CS005

Greet Wall

DELPHI DCM3.7 (EGR Actuator plug must be disconnected)

Honda

BOSCH EDC15C7 (EGR Actuator plug must be disconnected)

BOSCH EDC16C31

BOSCH EDC17_CP06 (EGR Actuator plug can be disconnected)

BOSCH EDC17_CP16 (EGR Actuator plug must be disconnected)

BOSCH EDC17_CP50 (EGR Actuator plug can be disconnected)

BOSCH EDC17C58 (EGR Actuator plug must be disconnected)

Hyundai

BOSCH EDC15C7 (EGR Actuator plug must be disconnected)

BOSCH EDC16C39 (EGR Actuator plug must be disconnected)

BOSCH EDC17_CP14 (EGR Actuator plug must be disconnected)

BOSCH EDC17_C08 (EGR Actuator plug can be disconnected)

BOSCH EDC17_C53 (EGR Actuator plug must be disconnected)

BOSCH EDC17_C57 (EGR Actuator plug must be disconnected)

BOSCH EDC17C08

BOSCH EDC17C09

BOSCH EDC17C10

DELPHI DDCR

DELPHI DCM3.7 (EGR Actuator plug can be disconnected)

Infiniti

DELPHI CRD3 (EGR Actuator plug must be disconnected)

BOSCH EDC16CP42 (EGR Actuator plug must be disconnected)

International

SIEMENS SID904 (EGR Actuator plug must be disconnected)

Isuzu

BOSCH EDC17_C83

DELPHI (EGR Actuator plug must be disconnected)

TRANSTRON (EGR Actuator plug must be disconnected)

Iveco

BOSCH EDC16C8

BOSCH EDC16C39 (EGR Actuator plug must be disconnected)

BOSCH EDC17C49

BOSCH EDC17CP52 (EGR Actuator plug must be disconnected)

Jaguar

SIEMENS SID204

BOSCH EDC17_CP11

BOSCH EDC17_CP42 (EGR Actuator plug must be disconnected)

BOSCH EDC17CP55 (EGR Actuator plug must be disconnected)

BOSCH MED17.0 - (EGR Actuator plug must be disconnected)

BOSCH MED17.8.3 - (EGR Actuator plug must be disconnected)

BOSCH MED17.8.31 - (EGR Actuator plug must be disconnected)

BOSCH MED17.9.7 - (EGR Actuator plug must be disconnected)

BOSCH MEDC17.9 (EGR Actuator plug must be disconnected)

DELPHI MPC555. (EGR Actuator plug must be disconnected)

SIEMENS SID201 (EGR Actuator plug must be disconnected)

SIEMENS SID803A

Jeep

BOSCH EDC15

BOSCH EDC16C2/CP31/U31

DELPHI CRD2-651

BOSCH EDC15C2 (EGR Actuator plug must be disconnected)

BOSCH EDC16C31

BOSCH EDC16CP31 (EGR Actuator plug must be disconnected)

BOSCH EDC17_C49 (EGR Actuator plug can be disconnected)

BOSCH EDC17C69 (EGR Actuator plug can be disconnected)

BOSCH EDC17_CP27

MOTOROLA NGC4 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

JMC

BOSCH EDC17_C63 - *IMPORTANT* ACTUATOR PLUG CAN BE
DISCONNECTED!

John Deere

PHOENIX Lxx (EGR Actuator plug must be disconnected)

Kia

BOSCH EDC15C7 (EGR Actuator plug must be disconnected)

BOSCH EDC16C39 (EGR Actuator plug must be disconnected)

BOSCH EDC17_CP14 (EGR Actuator plug must be disconnected)

BOSCH EDC17_C08 (EGR Actuator plug can be disconnected)

BOSCH EDC17_C53 (EGR Actuator plug must be disconnected)

BOSCH EDC17_C57 (EGR Actuator plug must be disconnected)

DELPHI DDCR

DELPHI DCM3.7 (EGR Actuator plug can be disconnected)

Kioti

DELPHI DCM3.7

Kubota

DENSO (EGR Actuator plug must be disconnected)

Lancia

BOSCH EDC16C8

BOSCH EDC16C9 BDM READ REQUIRED.

BOSCH EDC16C39 BDM READ REQUIRED.

BOSCH EDC17C69

MARELLI MJD6

MARELLI MJD8

Land Rover

BOSCH EDC16CP39 (EGR Actuator plug must be disconnected)

BOSCH EDC17_CP11 (EGR Actuator plug must be disconnected)

BOSCH EDC17_CP42 (EGR Actuator plug must be disconnected)

BOSCH EDC17CP55

BOSCH MED17.0 - *IMPORTANT* ACTUATOR PLUG MUST BE

DISCONNECTED!

BOSCH MED17.8.3 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.8.31 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MED17.9.7 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH MEDC17.9

SIEMENS SID201 (EGR Actuator plug must be disconnected)

SIEMENS SID202 (EGR Actuator plug must be disconnected)

SIEMENS SID203 (EGR Actuator plug must be disconnected)

SIEMENS SID204 (EGR Actuator plug must be disconnected)

SIEMENS SID206 (EGR Actuator plug must be disconnected)

SIEMENS SID208 (EGR Actuator plug must be disconnected)

VISTEON DCU102

VISTEON DCU106

VISTEON DCU10x

LDV

DELPHI DDCR (EGR Actuator plug must be disconnected)

Lexus

DENSO

MAN

BOSCH EDC7C32 (EGR Actuator plug must be disconnected)

Massey Ferguson

BOSCH EDC17CV54

Mazda

BOSCH EDC16C34 (EGR Actuator plug must be disconnected)

BOSCH EDC16C7

BOSCH EDC16C31

DENSO (EGR Actuator plug must be disconnected). RF7, RF8, SH12
ONLY!

BOSCH EDC16C3

DENSO R2AX

DENSO RF7x/RF8x

DENSO SH1/12/13/14

Mahindra

BOSCH EDC17_C63 - *IMPORTANT* ACTUATOR PLUG CAN BE DISCONNECTED!

BOSCH EDC17C53

Mercedes

BOSCH EDC15C0 (EGR Actuator plug must be disconnected)

BOSCH EDC15C6 (EGR Actuator plug must be disconnected)

BOSCH EDC15C7 (EGR Actuator plug must be disconnected)

BOSCH EDC16C3

BOSCH EDC16C31 (EGR Actuator plug must be disconnected) BDM
READ REQUIRED!

BOSCH EDC16C32 (EGR Actuator plug must be disconnected) BDM
READ REQUIRED!

BOSCH EDC16CP31 (EGR Actuator plug must be disconnected) BDM
READ REQUIRED!

BOSCH EDC16CP36 (EGR Actuator plug must be disconnected)

BOSCH EDC17_C42 (EGR Actuator plug must be disconnected)

BOSCH EDC17C43

BOSCH EDC17C66 (EGR Actuator plug must be disconnected)

BOSCH EDC17CP01

BOSCH EDC17CP10 (EGR Actuator plug must be disconnected)

BOSCH EDC17CP46

BOSCH ME2.8 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

DELPHI CRD1 (DCM3.2) - PROCESSOR/MPC ELEMENT REQUIRED.
(EGR Actuator plug must be disconnected)

DELPHI CRD2 (DCM3.5) (EGR Actuator plug must be disconnected)

DELPHI CRD3 (EGR Actuator plug must be disconnected)

SIEMENS SID307 (EGR Actuator plug must be disconnected)

SIEMENS SID309 (EGR Actuator plug must be disconnected)

SIEMENS SID310 (EGR Actuator plug must be disconnected)

TEMIC CRVx (EGR Actuator plug must be disconnected)

Mini

BOSCH EDC16C35 (EGR Actuator plug must be disconnected)

BOSCH EDC17_C41 (EGR Actuator plug must be disconnected)

Mitsubishi

BOSCH EDC15C3 (EGR Actuator plug must be disconnected)

BOSCH EDC16C31 (EGR Actuator plug must be disconnected) FULL
READ REQUIRED!

BOSCH EDC16CP39 (EGR Actuator plug must be disconnected)

BOSCH EDC16U31 FULL READ REQUIRED!

BOSCH EDC17C49 (EGR Actuator plug must be disconnected)

BOSCH EDC17CP15 (EGR Actuator plug must be disconnected)

BOSCH EDC17CP52 (EGR Actuator plug must be disconnected)

DENSO (EGR Actuator plug must be disconnected)

DENSO SH7058

New Holland

BOSCH EDC17C49 (EGR Actuator plug must be disconnected)

Nissan

BOSCH EDC15C3 (EGR Actuator plug must be disconnected)

BOSCH EDC16C3 (EGR Actuator plug must be disconnected)

BOSCH EDC16C41 (EGR Actuator plug must be disconnected)

BOSCH EDC17_C42 (EGR Actuator plug must be disconnected)

BOSCH EDC17_C84 (EGR Actuator plug must be disconnected)

DELPHI DCM3.5 (EGR Actuator plug can be disconnected)

BOSCH EDC16C36

BOSCH EDC16CP33

DELPHI DDCR (EGR Actuator plug must be disconnected)

DENSO (EGR Actuator plug must be disconnected)

DENSO SH7058

SIEMENS SID301 (EGR Actuator plug can be disconnected)

SIEMENS SID303 (EGR Actuator plug can be disconnected)

SIEMENS SID305 (EGR Actuator plug can be disconnected)

SIEMENS SID306 (EGR Actuator plug can be disconnected)

SIEMENS SID307 (EGR Actuator plug can be disconnected)

SIEMENS SID309 (EGR Actuator plug can be disconnected)

SIEMENS SID310 (EGR Actuator plug can be disconnected)

Opel

BOSCH EDC15C3 (EGR Actuator plug must be disconnected)

BOSCH EDC15C7

BOSCH EDC15M (EGR Actuator plug must be disconnected)

BOSCH EDC16C3 (EGR Actuator plug must be disconnected)

BOSCH EDC16C9 (EGR Actuator plug must be disconnected) BDM

READ REQUIRED!

BOSCH EDC16C36

BOSCH EDC16C39 (EGR Actuator plug must be disconnected) BDM

READ REQUIRED!

BOSCH EDC16CP33

BOSCH EDC17_C18

BOSCH EDC17_C19

BOSCH EDC17_C42

BOSCH EDC17_C59 (EGR Actuator plug must be disconnected)

BOSCH M1.5.5 (EGR Actuator plug must be disconnected) BETA.

BOSCH ME1.5.5 (EGR Actuator plug must be disconnected)

BOSCH ME7.6.1 (EGR Actuator plug can be disconnected)

BOSCH ME7.6.2 (EGR Actuator plug can be disconnected)

BOSCH ME7.6.3 (EGR Actuator plug can be disconnected)

BOSCH ME7.6.4 (EGR Actuator plug can be disconnected)

BOSCH ME7.6.6 (EGR Actuator plug can be disconnected)

BOSCH ME7.6.9 (EGR Actuator plug can be disconnected)

BOSCH PSG16 (EGR Actuator plug must be disconnected)

DELCO (Y17DT, Z16SE BETA, Z16XE BETA) (EGR Actuator plug must be disconnected)

DELCO E83 (EGR Actuator plug can be disconnected)

DELCO E87 (EGR Actuator plug must be disconnected)

DELCO E98 (EGR Actuator plug must be disconnected)

DELCO MT35. (EGR Actuator plug must be disconnected)

DELCO MULTEC. BETA. (EGR Actuator plug must be disconnected)

DELPHI DCM3.7 (EGR Actuator plug must be disconnected)

DENSO (EGR Actuator plug must be disconnected)

DENSO 29F400 / 512 KB FILES

DENSO SH7058/59

MARELLI MJD6

SIEMENS SID309

Porsche

BOSCH EDC17_CP44 (EGR Actuator plug must be disconnected)

Peugeot

BOSCH EDC15C2 (EGR Actuator plug must be disconnected)

BOSCH EDC15C3 (EGR Actuator plug must be disconnected)

BOSCH EDC16C0

BOSCH EDC16C34 (EGR Actuator plug must be disconnected)

BOSCH EDC16C39

BOSCH EDC16CP39 (EGR Actuator plug must be disconnected)

BOSCH EDC17_CP11 (EGR Actuator plug must be disconnected)

BOSCH EDC17C10 (EGR Actuator plug must be disconnected)

BOSCH EDC17C60 (EGR Actuator plug must be disconnected)

BOSCH EDC17_CP42

BOSCH EDC17CP52 (EGR Actuator plug must be disconnected)

DELPHI DCM3.4

DELPHI DCM3.5

DELPHI DCM6.2 (EGR Actuator plug must be disconnected)

DELPHI DDCR (EGR Actuator plug must be disconnected)

DENSO 29F400

MARELLI MJD6

MARELLI MJ8X (EGR Actuator plug must be disconnected)

SIEMENS SID201 (EGR Actuator plug must be disconnected)

MARELLI MJ8DF2

MARELLI MJ8DF3

SIEMENS SID208

SIEMENS SID801

SIEMENS SID802

SIEMENS SID803

SIEMENS SID803A

SIEMENS SID804 (EGR Actuator plug must be disconnected)

SIEMENS SID805 (EGR Actuator plug must be disconnected)

SIEMENS SID806

SIEMENS SID807 (EGR Actuator plug must be disconnected)

SIEMENS PPD

VISTEON DCU102

VISTEON DCU10X

Piaggio

BOSCH EDC17C08

Porsche

BOSCH EDC17CP14/CP44

Renault

BOSCH EDC15C3 (EGR Actuator plug must be disconnected)

BOSCH EDC16C3 (EGR Actuator plug must be disconnected)

BOSCH EDC16C36 (EGR Actuator plug can be disconnected)

BOSCH EDC16C41 (EGR Actuator plug must be disconnected)

BOSCH EDC16CP33 (EGR Actuator plug must be disconnected)

BOSCH EDC16CP39 (EGR Actuator plug must be disconnected)

BOSCH EDC17_C11 (EGR Actuator plug must be disconnected)

BOSCH EDC17_C42 (EGR Actuator plug must be disconnected)

BOSCH EDC17_C84 (EGR Actuator plug must be disconnected)

DELPHI DCM3.4 (EGR Actuator plug must be disconnected)

DELPHI DDCR (with 1.5 DCI only) (EGR Actuator plug must be disconnected)

SIEMENS SID301 (EGR Actuator plug can be disconnected)

SIEMENS SID305 (EGR Actuator plug can be disconnected)

SIEMENS SID306 (EGR Actuator plug can be disconnected)

SIEMENS SID307 (EGR Actuator plug can be disconnected)

SIEMENS SID309 (EGR Actuator plug can be disconnected))

SIEMENS SID310 (EGR Actuator plug can be disconnected)

Smart

BOSCH EDC15CG (EGR Actuator plug must be disconnected)

BOSCH EDC16C31 (EGR Actuator plug must be disconnected) BDM

READ REQUIRED!

BOSCH EDC16C32 (EGR Actuator plug must be disconnected) BDM

READ REQUIRED!

BOSCH EDC15

Saab

BOSCH EDC16C9 (EGR Actuator plug must be disconnected) BDM

READ REQUIRED!

BOSCH EDC16C39 (EGR Actuator plug must be disconnected) BDM

READ REQUIRED!

BOSCH PSG16 (EGR Actuator plug must be disconnected) BDM

READ REQUIRED!

Ssang Yong

DELPHI DCM3.2 (EGR Actuator plug must be disconnected)

DELPHI DCM3.7 (EGR Actuator plug must be disconnected)

Subaru

DENSO (EGR Actuator plug must be disconnected)

Suzuki

BOSCH EDC15C2 (EGR Actuator plug must be disconnected)

BOSCH EDC16C3 (EGR Actuator plug must be disconnected)

BOSCH EDC16C31 (EGR Actuator plug must be disconnected)

BOSCH EDC16C34

BOSCH EDC16C36 (EGR Actuator plug must be disconnected)

BOSCH EDC16C33

BOSCH EDC17_C49

BOSCH EDC17_C69

DELPHI DDCR (EGR Actuator plug must be disconnected)

SIEMENS SID801

Tata

DELPHI DCM3.2 (EGR Actuator plug must be disconnected)

DELPHI DCM3.7

Toyota

BOSCH EDC15C9 (EGR Actuator plug must be disconnected)

BOSCH EDC16C31 (EGR Actuator plug must be disconnected)

BOSCH EDC17_CP07 (EGR Actuator plug must be disconnected)

BOSCH EDC17_C73 (EGR Actuator plug must be disconnected)

DENSO (2.0D-4D/2.2D-4D)

DENSO

VAG

BOSCH EDC7C32

BOSCH EDC15P (EGR Actuator plug must be disconnected)

BOSCH EDC15V (EGR Actuator plug must be disconnected)

BOSCH EDC15VM (EGR Actuator plug must be disconnected)

BOSCH EDC16CP34 (EGR Actuator plug must be disconnected)

BOSCH EDC16U1 (EGR Actuator plug must be disconnected)

BOSCH EDC16U31 (EGR Actuator plug must be disconnected)

BOSCH EDC16U34 (EGR Actuator plug must be disconnected)

BOSCH EDC17_C46 (EGR Actuator plug must be disconnected)

BOSCH EDC17_C54

BOSCH EDC17_C64 (EGR Actuator plug must be disconnected)

BOSCH EDC17_C74 (EGR Actuator plug must be disconnected)

BOSCH EDC17_CP74 (EGR Actuator plug must be disconnected)

BOSCH EDC17_CP04 (EGR Actuator plug must be disconnected)

BOSCH EDC17_CP14 (EGR Actuator plug must be disconnected)

BOSCH EDC17_CP20 (EGR Actuator plug must be disconnected)

BOSCH EDC17_CP44 (EGR Actuator plug must be disconnected)

BOSCH EDC17_CP54 (EGR Actuator plug must be disconnected)

BOSCH EDC17_U01

BOSCH EDC17_U05

BOSCH MD1_CP004 (EGR Actuator plug must be disconnected)

BOSCH MD1_CP014 (EGR Actuator plug must be disconnected)

BOSCH MD1_CS004 (EGR Actuator plug must be disconnected)

BOSCH MDG1 (MG1CS011)

BOSCH MG1CS001 (EGR Actuator plug must be disconnected)

BOSCH MG1CS002 (EGR Actuator plug must be disconnected)

BOSCH ME7.5 (EGR Actuator plug must be disconnected)

BOSCH ME7.5.10 (EGR Actuator plug must be disconnected)

BOSCH ME7.5.20 (EGR Actuator plug must be disconnected)

BOSCH MED9.1 (EGR Actuator plug must be disconnected)

BOSCH MED9.5.10 (EGR Actuator plug must be disconnected)

DELPHI DCM3.7 (EGR Actuator plug must be disconnected)

DELPHI DCM6.2 (EGR Actuator plug must be disconnected)

MARELLI IAW 4MV

SIEMENS PCR2.1

SIEMENS PPD

SIEMENS SIMOS 3 (EGR Actuator plug must be disconnected)

Volvo

BOSCH EDC15C2 (EGR Actuator plug must be disconnected)

BOSCH EDC15C3 (EGR Actuator plug must be disconnected)

BOSCH EDC15C11 (EGR Actuator plug must be disconnected)

BOSCH EDC16C34 (EGR Actuator plug must be disconnected)

BOSCH EDC16C31

BOSCH EDC17_CP22 (EGR Actuator plug must be disconnected)

BOSCH EDC17_CP48 (EGR Actuator plug must be disconnected)

BOSCH EDC17_CP68 (EGR Actuator plug must be disconnected)

BOSCH MSA15 (EGR Actuator plug must be disconnected)

SIEMENS SID803

SIEMENS SID803A

SIEMENS SID807 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

DENSO VEA (EGR Actuator plug must be disconnected)

DTC Removal Module

Audi/Seat/Skoda/Volkswagen/Porsche

Bosch EDC15P/VM+

Bosch EDC16 (BDM)

Bosch EDC16CP34

Bosch EDC16U1/U31/U34

Bosch EDC17C46/C54

Bosch EDC17C64

Bosch EDC17CP04/CP14/CP20

Bosch EDC17U01/U05

Bosch ME7.1/7.5/7.5.1/7.5.10 (C167)

Bosch ME7.2/7.8

Bosch MED17.1/17.1.1/17.5

Bosch MED9.1/9.1.2

Delphi DCM3.7

Siemens PPD

Siemens Simos 3

Siemens Simos 7.1

Siemens Simos 9.1

Siemens Simos PCR2.1

AEBI SCHMIDT

BOSCH EDC16C39

Alfa Romeo

BOSCH EDC15C2

BOSCH EDC15C5

BOSCH EDC15C7

BOSCH EDC16C8

BOSCH EDC16C39

BOSCH EDC17C49

BOSCH EDC17C69

BOSCH ME7.3.1

BOSCH ME7.9.10

BOSCH ME17.3.0

BOSCH MED17.3.3

Bentley

BOSCH ME7.1.1

BOSCH MD1_CP014

BMW

BOSCH EDC15C4

BOSCH EDC16C31

BOSCH EDC16C35

BOSCH EDC16CP35

BOSCH EDC17_C06

BOSCH EDC17_C41

BOSCH EDC17_C50

BOSCH EDC17_C56

BOSCH EDC17_C76

BOSCH EDC17_CP02

BOSCH EDC17_CP09

BOSCH EDC17_CP45

BOSCH EDC17_CP49

BOSCH ME7.2

BOSCH MED17X

BOSCH MEVD17.2

BOSCH MEVD17.2.5

BOSCH MEVD17.2.6

BOSCH MEVD17.2.8

BOSCH MEVD17.2.9

BOSCH MEVD17.2.G

BOSCH MD1CP002

BOSCH MDG1_MD1CS001

BOSCH MG1CS003

BOSCH MG1CS024

BOSCH MG1CS201

Case

BOSCH EDC17C49

BOSCH EDC17CV41

Chery

BOSCH ME7.9.71

Chevrolet

BOSCH EDC16C39

BOSCH EDC17_C59

BOSCH EDC17_CP18

BOSCH EDC17_CP47

BOSCH ME7.9.9

Delphi DCM3.7

Chrysler

BOSCH EDC15C2

BOSCH EDC15C7

BOSCH EDC16CP31

Bosch EDC16C31

Bosch EDC16U31

Delphi CRD2-651

Citroen

BOSCH EDC15C2

BOSCH EDC15C7

Bosch EDC16 (BDM)

BOSCH EDC16C0

BOSCH EDC16C34

BOSCH EDC16C39

BOSCH EDC16CP39

BOSCH EDC17_C10

BOSCH EDC17_CP11

BOSCH EDC17_CP42

BOSCH EDC17C10

BOSCH EDC17C60

BOSCH EDC17CP10

BOSCH M7.9.5

BOSCH ME7.4.4

BOSCH ME7.4.5

BOSCH ME7.4.6

BOSCH ME7.4.7

BOSCH ME7.9.52

BOSCH MED17.4

BOSCH MEV17.4

BOSCH MED17.4.2

BOSCH MED17.4.4

BOSCH MEVD17.4.2

BOSCH MEVD17.4.4

BOSCH MD1CS003

Continental SID208

Continental SID807

DELPHI DCM3.4

DELPHI DCM3.5

DELPHI DCM6.2

SIEMENS SID201

SIEMENS SID201A

SIEMENS SID803

SIEMENS SID803A

SIEMENS SID807

SIEMENS SID804

VISTEON DCU102

Dacia

SIEMENS SID310

Continental SID306

Deutz

BOSCH EDC16UC40

Dodge

BOSCH EDC16CP31

BOSCH EDC16U31

BOSCH EDC17_C79

Bosch EDC15C7

Bosch EDC16C31

Delphi CRD2-651

Dongfeng

BOSCH EDC17CV54

Doosan

BOSCH EDC17CV41

FAW

BOSCH EDC17CV44

Fendt

BOSCH EDC7UC31

BOSCH EDC17CV56

Ferrari

BOSCH MED17.3.5

Fiat

BOSCH EDC15C2

BOSCH EDC15C7

BOSCH EDC16C8

BOSCH EDC16C34

BOSCH EDC16C39 BDM READ REQUIRED.

BOSCH EDC17C49

BOSCH EDC17C69

BOSCH EDC17_C10

BOSCH EDC17_C49

BOSCH EDC17CP52

BOSCH ME7.3.1

BOSCH ME7.9.10

BOSCH ME17.3.0

DELPHI DCM3.5

MARELLI MJD6F

MARELLI MJ8

MARELLI MJ9

SIEMENS SID803A

VISTEON DCU102

Ford

BOSCH EDC15P

BOSCH EDC16C3

BOSCH EDC16C7

BOSCH EDC16C31

BOSCH EDC16C34

BOSCH EDC17_C10

BOSCH EDC17_CP05

BOSCH EDC17_CP42

BOSCH EDC17CP65

BOSCH EDC17C70

BOSCH EDC7UC31

BOSCH MD1CS005

BOSCH MED17

Continental SID208

Continental SID807

DELPHI DCM3.5

DELPHI MPC555

SIEMENS SID202

SIEMENS SID206

SIEMENS SID208

SIEMENS SID209

SIEMENS SID211

SIEMENS SID803

SIEMENS SID803A

SIEMENS SID807

VISTEON DCU102

VISTEON DCU106

VISTEON DCU201

GHEL

BOSCH EDC17CV54

Hino

DENSO

HondaBOSCH ME7.4.4

BOSCH EDC15C7

BOSCH EDC16C31

BOSCH EDC17_CP06

BOSCH EDC17_CP16

BOSCH EDC17_CP50

BOSCH EDC17C58

BOSCH MED17.9.3

Alfa/Fiat/Lancia Bosch EDC15C2

Alfa/Fiat/Lancia Bosch EDC15C7

Alfa/Fiat/Lancia Bosch EDC16 (BDM)

Alfa/Fiat/Lancia Bosch EDC16C8

Alfa/Fiat/Lancia Bosch EDC16C9/C39

Alfa/Fiat/Lancia Bosch EDC17C49

Alfa/Fiat/Lancia Bosch ME7.9.10

Alfa/Fiat/Lancia Marelli 6JF/6F3/8F2/8F3

Alfa/Fiat/Lancia Siemens SID803A

Hyundai

BOSCH EDC15C7

BOSCH EDC16C39 (BDM READ REQUIRED)

BOSCH EDC17_C08

BOSCH EDC17_C53

BOSCH EDC17_C57

BOSCH EDC17_CP14

BOSCH ME7.9.6

BOSCH MED17.9.8

Honda

Bosch EDC16 (BDM)

Bosch EDC16C31

Infiniti

BOSCH EDC16CP42

DELPHI CRD3

Iveco

BOSCH EDC16C39

BOSCH EDC17C49

BOSCH EDC17C69

BOSCH EDC17CP52

BOSCH EDC17CV41

BOSCH EDC7UC31

Isuzu

TRANSTRON

BOSCH EDC17CV41

BOSCH EDC17_C83

DELPHI 4J

JAC

BOSCH EDC17_C53

Jaguar

BOSCH EDC17_CP11

BOSCH EDC17_CP42

BOSCH MED17.0

BOSCH MED17.8.3

BOSCH MED17.8.31

BOSCH MED17.9.7

BOSCH MEDC17.9

DELPHI MPC555

SIEMENS SID201

SIEMENS SID204

Jeep

BOSCH EDC15C2

BOSCH EDC16C31

BOSCH EDC16CP31

BOSCH EDC16U31

BOSCH EDC17_CP27

BOSCH EDC17_C49

BOSCH EDC17_C79

BOSCH EDC17C49

BOSCH EDC17C69

Bosch EDC15C7

Delphi CRD2-651

Jinbei

BOSCH EDC17_C81

JMC

BOSCH EDC17_C63

BOSCH EDC17_C81

Kia

BOSCH EDC15C7

BOSCH EDC16C39 (BDM READ REQUIRED)

BOSCH EDC17_C08

BOSCH EDC17_C53

BOSCH EDC17_C57

BOSCH EDC17_CP14

Kobelco

BOSCH EDC17CV54

Lancia

BOSCH EDC15C2

BOSCH EDC16C9

BOSCH EDC16C39 BDM READ REQUIRED.

BOSCH EDC17_C49

BOSCH EDC17_CP27

BOSCH ME7.3.1

Land Rover

BOSCH EDC15C4

BOSCH EDC16CP39

BOSCH EDC17_CP11

BOSCH EDC17_CP42

BOSCH EDC17CP55

BOSCH ME7.2

BOSCH MED17.8.3

BOSCH MED17.8.31

BOSCH MED17.9.7

BOSCH MEDC17.9

SIEMENS SID201

SIEMENS SID204

SIEMENS SID208

VISTEON DCU102

VISTEON DCU106

LDV

BOSCH EDC17_C53

BOSCH EDC17_C81

Lexus

DENSO

Iveco

Bosch EDC16 (BDM)

Bosch EDC16 C39

Mahindra

BOSCH EDC16C39

BOSCH EDC17_C53

BOSCH EDC17_C63

BOSCH EDC17_C81

Mazda

BOSCH EDC16C3

BOSCH EDC16C7

BOSCH EDC16C34

DENSO RXX / SHXX

SIEMENS SID807

TRANSTRON

Denso R2A/RF7/RFA

Siemens SID804

Maserati

BOSCH ME7.1.3

BOSCH MED17.3.4

BOSCH EDC17_C79

McLaren

BOSCH ME17.8.32

Mercedes

BOSCH EDC15C0

BOSCH EDC15C6

BOSCH EDC16C31 (BDM READ REQUIRED)

BOSCH EDC16C32 (BDM READ REQUIRED)

BOSCH EDC16CP31 (BDM READ REQUIRED)

BOSCH EDC16CP36

BOSCH EDC17CP01

BOSCH EDC17_C42

BOSCH EDC17_CP11

BOSCH EDC17C43

BOSCH EDC17C66

BOSCH EDC17CP10

BOSCH EDC17CP46

BOSCH EDC17CP57

BOSCH MD1CP001

BOSCH ME9.7

BOSCH MED17X

BOSCH MG1CP002

Delphi CRD2-651

Delphi CRD3-651

DELPHI DCM3.2

DELPHI CRD2.x

DELPHI CRD3.x

SIEMENS SID307

SIEMENS SID310

Mini

Bosch EDC16 (BDM)

BOSCH EDC16C35

BOSCH EDC17_C41

BOSCH MEVD17.2

BOSCH MEVD17.2.2

BOSCH MEVD17.2.3

BOSCH MEVD17.2.5

BOSCH MEVD17.2.6

BOSCH MEVD17.2.8

BOSCH MEVD17.2.9

BOSCH MEVD17.2.G

Mitsubishi

BOSCH EDC15C3

Bosch EDC16 (BDM)

BOSCH EDC16C31 FULL READ REQUIRED!

BOSCH EDC16U31 FULL READ REQUIRED!

BOSCH EDC16CP39

BOSCH EDC17C49

BOSCH EDC17CP15

BOSCH EDC17_CP16

BOSCH EDC17CP52

DENSO

New Holland

BOSCH EDC7UC31

BOSCH EDC17C49

Nissan

BOSCH EDC15C3

BOSCH EDC15C7

BOSCH EDC15VM

BOSCH EDC16C3

BOSCH EDC16C41

BOSCH EDC16CP33

BOSCH EDC16CP42

BOSCH EDC17_C11

BOSCH EDC17_C42

BOSCH EDC17_C84

BOSCH EDC17_CP45

Bosch EDC16C36

Continental SID301/303

Continental SID305/306

Continental SID307

DENSO

SIEMENS SID305

SIEMENS SID306

SIEMENS SID307

SIEMENS SID309

SIEMENS SID310

Opel

BOSCH EDC15C3

BOSCH EDC16C3

BOSCH EDC16C9 (BDM READ REQUIRED)

BOSCH EDC16C36

BOSCH EDC16C39 (BDM READ REQUIRED)

BOSCH EDC16CP33

BOSCH EDC17_C11

BOSCH EDC17_C18

BOSCH EDC17_C19

BOSCH EDC17_C42

BOSCH EDC17_C59

BOSCH EDC17C69

BOSCH EDC17_C84

BOSCH EDC17_CP47

BOSCH ME1.5.5

BOSCH ME3.1.1

BOSCH ME7.6.1

BOSCH ME7.6.2

BOSCH ME7.6.3

BOSCH ME7.6.4

BOSCH ME7.9.6

BOSCH ME7.9.9

BOSCH PSG16

Delphi DCM3.7

Denso SH7058/59

Marelli 6JO/6O2/6O3

MARELLI MJD6F

DENSO

DELCO E83

DELCO E87

DELCO E98

Peugeot

BOSCH EDC15C2

BOSCH EDC15C7

Bosch EDC16 (BDM)

BOSCH EDC16C0

BOSCH EDC16C34

BOSCH EDC16C39

BOSCH EDC16CP39

BOSCH EDC17_C10

BOSCH EDC17_CP11

BOSCH EDC17_CP42

BOSCH EDC17C10

BOSCH EDC17C60

BOSCH EDC17CP10

BOSCH M7.9.5

BOSCH ME7.4.4

BOSCH ME7.4.5

BOSCH ME7.4.6

BOSCH ME7.4.7

BOSCH ME7.4.9

BOSCH ME7.9.52

BOSCH MED17.4

BOSCH MEV17.4

BOSCH MED17.4.2

BOSCH MED17.4.4

BOSCH MEVD17.4.2

BOSCH MEVD17.4.4

BOSCH MD1CS003

Continental SID208

Continental SID807

DELPHI DCM3.4

DELPHI DCM3.5

DELPHI DCM6.2

SIEMENS SID201

SIEMENS SID201A

SIEMENS SID803

SIEMENS SID803A

SIEMENS SID807

SIEMENS SID804

VISTEON DCU102

Piaggio

BOSCH EDC17_C08

Porsche

BOSCH EDC17_CP14

BOSCH EDC17_CP44

BOSCH ME7.1.1

BOSCH ME7.8

Renault

BOSCH EDC15C3

BOSCH EDC16C3

BOSCH EDC16C36

BOSCH EDC16CP33

BOSCH EDC16CP42

BOSCH EDC17_C11

BOSCH EDC17_C42

BOSCH EDC17_C84

BOSCH EDC17_CP19

BOSCH EDC17_CP54

BOSCH EDC17_CP58

BOSCH ME17.9.20

Continental SID301/303

Continental SID305/306

Continental SID307

DENSO

SIEMENS SID305

SIEMENS SID306

SIEMENS SID307

SIEMENS SID309

SIEMENS SID310

Saab

BOSCH EDC16C9 (BDM READ REQUIRED)

BOSCH EDC16C39 (BDM READ REQUIRED)

BOSCH EDC17_CP21

BOSCH PSG16

Smart

BOSCH EDC16C31 (BDM READ REQUIRED)

BOSCH EDC16C32 (BDM READ REQUIRED)

BOSCH ME7.7.0

BOSCH ME17.7

Ssang Yong

DELPHI DCM3.2

Subaru

BOSCH EDC16C36

BOSCH EDC17_CP02

Denso (2.0D)

DENSO

Suzuki

BOSCH EDC15C2

BOSCH EDC16C3

BOSCH EDC16C34

BOSCH EDC16C39

BOSCH EDC17_C49

BOSCH EDC17_C69

BOSCH MED17.9.63

BOSCH MED17.8

Marelli 6JO/6F3

Marelli 8DS

Toyota

BOSCH EDC15C9

BOSCH EDC16C31

BOSCH EDC17_CP07

BOSCH EDC17_C73

Denso (2.0D/2.2D)

DENSO

VAG

BOSCH EDC15P

BOSCH EDC15V

BOSCH EDC15VM

BOSCH EDC16C4

BOSCH EDC16CP34

BOSCH EDC16U1

BOSCH EDC16U31

BOSCH EDC16U34

BOSCH EDC17_U01

BOSCH EDC17_U05

BOSCH EDC17_CP04

BOSCH EDC17_CP14

BOSCH EDC17_CP20

BOSCH EDC17_CP24

BOSCH EDC17_CP44

BOSCH EDC17_CP54

BOSCH EDC17_C46

BOSCH EDC17_C54

BOSCH EDC17C64

BOSCH EDC17C74

BOSCH EDC17CP74

BOSCH ME7.1

BOSCH ME7.1.1

BOSCH ME7.5

BOSCH ME7.5.10

BOSCH ME7.5.20

BOSCH ME7.5.30

BOSCH MED7.1.1

BOSCH MED7.5.11

BOSCH MED9.1

BOSCH MED9.5.10

BOSCH MED17

BOSCH MED17.1

BOSCH MED17.6

BOSCH MED17.1.1

BOSCH MED17.1.6

BOSCH MED17.1.21

BOSCH MED17.1.27

BOSCH MED17.1.61

BOSCH MED17.1.62

BOSCH MED17.5

BOSCH MED17.5.2

BOSCH MED17.5.5

BOSCH MED17.5.20

BOSCH MED17.5.21

BOSCH MED17.5.24

BOSCH MED17.5.25

BOSCH MED17.5.26

BOSCH MG1CS001

BOSCH MG1CS002

BOSCH MDG1 (MG1CS011)

BOSCH MD1_CP004

BOSCH MD1_CP014

BOSCH MD1_CS004

DELPHI DCM3.7

DELPHI DCM6.2

SIEMENS PCR2.1

SIEMENS PPD1.1

SIEMENS PPD1.2

SIEMENS PPD1.3

SIEMENS PPD1.5

SIEMENS SIMOS 10

SIEMENS SIMOS 11

SIEMENS SIMOS 12

SIEMENS SIMOS 18

Volvo

BOSCH EDC16C31

Bosch EDC16C34

BOSCH EDC17_CP22

BOSCH EDC17_CP48

BOSCH EDC17_CP68

BOSCH ME7.0.1

BOSCH ME7.1

SIEMENS SID206

SIEMENS SID803

SIEMENS SID803A

SIEMENS SID807

ADBlue Removal Module (尿素故障关闭列表)

ALEXANDER DENNIS

CUMMINS CM2150E - COMBINATED SOLUTION. SCR AND NOX FUSES / RELAYS, ADBLUE UNIT AND NOX SENSORS MUST BE DISCONNECTED!

ASTRA

BOSCH EDC7UC31 - COMBINATED SOLUTION. ADBLUE UNIT AND PUMP MUST BE DISCONNECTED.

BMC

CUMMINS CM850 - COMBINATED SOLUTION. SCR FUSE MUST BE DISCONNECTED!

CUMMINS CM2150E - COMBINATED SOLUTION. SCR AND NOX FUSES / RELAYS, ADBLUE UNIT AND NOX SENSORS MUST BE DISCONNECTED!

BMW

BOSCH EDC17_C41 - SWITCH SOLUTION. NOX SENSORS AND PUMP CAN BE DISCONNECTED!

BOSCH EDC17_C50 - SWITCH SOLUTION. NOX SENSORS AND PUMP

MUST BE DISCONNECTED!

BOSCH EDC17_C56 - SWITCH SOLUTION. SCR PLUG HAVE BE DISCONNECTED. DASH MIGHT NEED TO BE RECODED. NOX SENSORS CAN BE DISCONNECTED!

BOSCH EDC17_CP09 - SWITCH SOLUTION. PUMP CAN BE DISCONNECTED. SENSORS CAN BE DISCONNECTED!

BOSCH EDC17_CP45 - SWITCH SOLUTION. PUMP MUST BE DISCONNECTED. SENSORS CAN BE DISCONNECTED!

BOSCH EDC17_CP49 - SWITCH SOLUTION. PUMP CAN BE DISCONNECTED. SENSORS CAN BE DISCONNECTED!

BOBCAT

BOSCH DCU17CV51 - *IMPORTANT* ADBLUE UNIT / PUMP MUST BE DISCONNECTED!

CAMC

BOSCH EDC17CV44 - COMBINATED SOLUTION. ADBLUE ECU AND PUMP MUST BE DISCONNECTED!

CASE

BOSCH EDC7UC31 - COMBINATED SOLUTION. ADBLUE UNIT AND PUMP MUST BE DISCONNECTED!

BOSCH EDC17_C49 - COMBINATED SOLUTION. ADBLUE ECU AND PUMP MUST BE DISCONNECTED!

BOSCH EDC17CV41 - SWITCH SOLUTION. ADBLUE ECU AND PUMP MUST BE DISCONNECTED!

Challenger

BOSCH EDC17_CV54. ADBLUE PUMP MUST BE DISCONNECTED

Chevrolet

BOSCH EDC17_CP18 - SWITCH SOLUTION. ADBLUE ECU AND NOx SENSORS CAN BE DISCONNECTED!

BOSCH EDC17_CP47 - SWITCH SOLUTION. NOx SENSORS CAN BE DISCONNECTED!

Citroen

BOSCH EDC17_C10 - SWITCH SOLUTION. ADBLUE ECU AND PUMP MUST BE DISCONNECTED!

BOSCH EDC17_C60 - SWITCH SOLUTION. ADBLUE ECU AND PUMP MUST BE DISCONNECTED!

DELPHI DCM6.2 - COMBINATED SOLUTION.

Claas

BOSCH EDC17CV41 - COMBINATED SOLUTION.

TEMIC PLD2 - COMBINATED SOLUTION. ADBLUE UNIT MUST BE DISCONNECTED. NOx SENSORS CAN BE DISCONNECTED!

TEMIC ACM - *IMPORTANT* ADBLUE PUMP MUST BE DISCONNECTED!

DACIA

BOSCH EDC17_C84 - COMBINATED SOLUTION. ADBLUE UNIT AND PUMP MUST BE DISCONNECTED.

DAF

BOSCH EAS (DELPHI DMCI) - COMBINATED SOLUTION. ADBLUE PUMP, TANK AND NOX SENSORS MUST BE DISCONNECTED

DELPHI DMCI - COMBINATED SOLUTION. SCR FUSE MUST BE DISCONNECTED. BETA - LIGHT IS "ON" ON DASH

DELPHI ETC3 - COMBINATED SOLUTION. PUMP PLUG MUST BE DISCONNECTED.

MOTOROLA CM850 - COMBINATED SOLUTION. SCR FUSE MUST BE REMOVED.

Deutz

BOSCH EDC17CV52 - COMBINATED SOLUTION. ADBLUE UNIT, PUMP AND TANK MUST BE DISCONNECTED!

BOSCH EDC17CV56 - COMBINATED SOLUTION. ADBLUE ECU CAN BE DISCONNECTED!

Dingo

BOSCH EDC17CV52 - COMBINATED SOLUTION. ADBLUE ECU MUST BE DISCONNECTED!

Dodge

BOSCH EDC17C79 / EDC17_C79 - SWITCH SOLUTION. ADBLUE ECU AND NOx SENSORS CAN BE DISCONNECTED!

Doosan

BOSCH EDC17CV41 - SWITCH SOLUTION. ADBLUE ECU CAN BE DISCONNECTED!

CAT ADEM5 - COMBINATED SOLUTION. ADBLUE ECU MUST BE DISCONNECTED!

FAW

BOSCH EDC17CV44 - COMBINATED SOLUTION. ADBLUE UNIT MUST BE DISCONNECTED.

Fendt

BOSCH EDC17CV52 - SWITCH SOLUTION. ADBLUE UNIT AND PUMP MUST BE DISCONNECTED!

BOSCH EDC17CV56 - COMBINATED SOLUTION. ADBLUE UNIT AND PUMP MUST BE DISCONNECTED!

Fiat

BOSCH EDC17C49 - SWITCH SOLUTION. ADBLUE ECU AND NOx SENSORS CAN BE DISCONNECTED!

Ford

BOSCH EDC17_C10 - SWITCH SOLUTION. ADBLUE ECU AND PUMP MUST BE DISCONNECTED!

BOSCH EDC17_CP05 - SWITCH SOLUTION.

CUMMINS CM2150E - COMBINATED SOLUTION. SCR AND NOX FUSES / RELAYS, ADBLUE UNIT AND NOX SENSORS MUST BE DISCONNECTED!

SIEMENS SID209 - COMBINATED SOLUTION. ADBLUE PUMP MUST BE DISCONNECTED.

SIEMENS SID211 - COMBINATED SOLUTION.

Halcon

PERKINS *BETA*

Hino

DENSO SH7058 - COMBINATED SOLUTION. SCR FUSE MUST BE

DISCONNECTED.

HOWO

DENSO - COMBINATED SOLUTION. BETA. ADBLUE UNIT AND PUMP
MUST BE DISCONNECTED.

Hyundai

CUMMINS CM2350 - COMBINATED SOLUTION. SCR AND NOX FUSES
/ RELAYS, ADBLUE UNIT AND NOX SENSORS MUST BE
DISCONNECTED!

BOSCH EDC17_C57

Isuzu

BOSCH EDC7CV41 - COMBINATED SOLUTION. ADBLUE UNIT AND
PUMP MUST BE DISCONNECTED

Iveco

BOSCH EDC7UC31 - COMBINATED SOLUTION. ADBLUE UNIT AND
PUMP MUST BE DISCONNECTED. NOx SENSORS CAN BE
DISCONNECTED!

BOSCH EDC17C49 - SWITCH SOLUTION. ADBLUE ECU AND NOx
SENSORS CAN BE DISCONNECTED!

BOSCH EDC17CV41 - SWITCH SOLUTION. ADBLUE ECU MUST BE

DISCONNECTED.

BOSCH EDC17CP52 - SWITCH SOLUTION.

CUMMINS CM2150E - COMBINATED SOLUTION. AFTERTREATMENT
ECU MUST BE DISCONNECTED!

Jaguar

BOSCH EDC17CP55 - SWITCH SOLUTION. NOx SENSORS CAN BE
DISCONNECTED!

BOSCH MEDC17.9 - SWITCH SOLUTION. NOx SENSORS CAN BE
DISCONNECTED!

JCB

BOSCH EDC17CV41 - SWITCH SOLUTION.

BOSCH EDC17CV44 - SWITCH SOLUTION.

BOSCH EDC17CV54 - SWITCH SOLUTION.

Jeep

BOSCH EDC17_C79 - SWITCH SOLUTION. NOx SENSORS CAN BE
DISCONNECTED!

John Deere

PHOENIX L3X - COMBINATED SOLUTION. SCR AND NOX FUSES /
RELAYS, ADBLUE UNIT AND NOX SENSORS MUST BE DISCONNECTED!

BETA.

PHOENIX L2x - COMBINATED SOLUTION *BETA*

Kamaz

CUMMINS CM2150E - COMBINATED SOLUTION. SCR AND NOX FUSES / RELAYS, ADBLUE UNIT AND NOX SENSORS MUST BE DISCONNECTED!

Kenworth

CUMMINS CM2250. AFTERTREATMENT ECU MUST BE DISCONNECTED!

King Long

CUMMINS CM850

Kubota

DENSO

Land Rover

BOSCH EDC17CP55 - SWITCH SOLUTION. NOx SENSORS CAN BE DISCONNECTED!

BOSCH MEDC17.9 - SWITCH SOLUTION. NOx SENSORS CAN BE DISCONNECTED!

Laverda

BOSCH EDC17CV44 - SWITCH SOLUTION. ADBLUE UNIT MUST BE DISCONNECTED. NOx SENSORS CAN BE DISCONNECTED!

BOSCH EDC17CV54 - SWITCH SOLUTION. ADBLUE UNIT MUST BE DISCONNECTED. NOx SENSORS CAN BE DISCONNECTED!

MAN

BOSCH EDC7C32 - COMBINATED SOLUTION. ADBLUE ECU / FUSE MUST BE DISCONNECTED. WARNING - DASH REQUIRE RECODING.

BOSCH EDC7C32 - VDF SOLUTION.

BOSCH EDC17CV42 - COMBINATED SOLUTION. ADBLUE ECU / FUSE MUST BE DISCONNECTED.

Massey Ferguson

BOSCH EDC17CV41 - SWITCH SOLUTION.

BOSCH EDC17CV44 - SWITCH SOLUTION.

BOSCH EDC17CV54 - SWITCH SOLUTION. ADBLUE UNIT AND PUMP MUST BE DISCONNECTED.

Maz

TEMIC PLD EU4 / EU5 - COMBINATED SOLUTION. PLUG FROM ADBLUE MODULE MUST BE DISCONNECTED. NOx SENSORS CAN BE DISCONNECTED!

Maserati

BOSCH EDC17_C79 - SWITCH SOLUTION.

Mazda

DENSO - COMBINATED SOLUTION. ADBLUE ECU (NEAR EXHAUST PIPES OR UNDER THE DRIVER'S SEAT) AND SCR FUSE MUST BE DISCONNECTED.

Mercedes

BOSCH EDC17C66 - COMBINATED SOLUTION. PLUG FROM ADBLUE MODULE MUST BE DISCONNECTED.

BOSCH EDC17CP10 - COMBINATED SOLUTION. PLUG FROM ADBLUE MODULE MUST BE DISCONNECTED. NOX SENSORS CAN BE DISCONNECTED.

BOSCH EDC17CP46 - COMBINATED SOLUTION. PLUG FROM ADBLUE MODULE MUST BE DISCONNECTED. SENSORS CAN BE DISCONNECTED!

BOSCH EDC17CP57 - COMBINATED SOLUTION. ADBLUE ECU AND NOx SENSORS MUST BE DISCONNECTED!

DELPHI CRD3 - COMBINATED SOLUTION. PLUG FROM ADBLUE MODULE MUST BE DISCONNECTED.

BOSCH MD1CP001 - *IMPORTANT* ADBLUE UNIT MUST BE

DISCONNECTED!

Mercedes Truck

TEMIC PLD EU4 / EU5 - COMBINATED SOLUTION. PLUG FROM ADBLUE MODULE MUST BE DISCONNECTED. NO_x SENSORS CAN BE DISCONNECTED!

TEMIC PLD2 EU5 - COMBINATED SOLUTION. PLUG FROM ADBLUE MODULE MUST BE DISCONNECTED. NO_x SENSORS CAN BE DISCONNECTED!

TEMIC ACM - COMBINATED SOLUTION. ADBLUE PUMP MUST BE DISCONNECTED. NO_x SENSORS MUST BE DISCONNECTED!

Mitsubishi

BOSCH EDC16C31 - COMBINATED SOLUTION. ADBLUE UNIT AND PUMP MUST BE DISCONNECTED.

BOSCH EDC17CP15 - COMBINATED SOLUTION. ADBLUE UNIT MUST BE DISCONNECTED. NO_x SENSORS CAN BE DISCONNECTED!

BOSCH EDC17C49 - SWITCH SOLUTION.

BOSCH EDC17CP52 - SWITCH SOLUTION.

TEMIC ACM - COMBINATED SOLUTION. ADBLUE PUMP MUST BE DISCONNECTED.

New Holland

BOSCH EDC7UC31 - COMBINATED SOLUTION. ADBLUE UNIT AND PUMP MUST BE DISCONNECTED. NOx SENSORS CAN BE DISCONNECTED!

BOSCH EDC17CV41 - SWITCH SOLUTION. ADBLUE UNIT AND PUMP MUST BE DISCONNECTED.

Nissan

BOSCH EDC17_C45 - COMBINATED SOLUTION

BOSCH EDC17_C84 - COMBINATED SOLUTION. ADBLUE UNIT AND PUMP MUST BE DISCONNECTED.

Nissan Truck

TRW EMS2 - COMBINATED SOLUTION. ADBLUE FUSE OR SCR INJECTION MUST BE DISCONNECTED.

MOTOROLA CM850 - COMBINATED SOLUTION. ADBLUE FUSE MUST BE DISCONNECTED.

Opel

BOSCH EDC17_C84 - COMBINATED SOLUTION. ADBLUE UNIT AND PUMP MUST BE DISCONNECTED.

Peugeot

BOSCH EDC17_C10 - SWITCH SOLUTION. ADBLUE ECU AND PUMP MUST BE DISCONNECTED!

BOSCH EDC17_C60 - SWITCH SOLUTION. ADBLUE ECU AND PUMP MUST BE DISCONNECTED!

DELPHI DCM6.2 - COMBINATED SOLUTION.

Ponsse

TEMIC PLD2 - SWITCH SOLUTION. COMBINATED SOLUTION. PLUG FROM ADBLUE MODULE MUST BE DISCONNECTED. NOx SENSORS CAN BE DISCONNECTED!

Porsche

BOSCH EDC17_CP44 - COMBINATED SOLUTION. NOX SENSORS CAN BE DISCONNECTED.

Renault

BOSCH EDC17_C84 - COMBINATED SOLUTION. ADBLUE UNIT AND PUMP MUST BE DISCONNECTED.

SIEMENS SID310 - COMBINATED SOLUTION.

Renault Trucks

TRW EMS2 EU5 - COMBINATED SOLUTION. SCR FUSE OR SCR INJECTION MUST BE DISCONNECTED.

Scania

MOTOROLA EMS S6 - SWITCH SOLUTION. SCR FUSE / PUMP / TANK MUST BE DISCONNECTED.

Solaris

CUMMINS CM2150E - COMBINATED SOLUTION. SCR AND NOX FUSES / RELAYS, ADBLUE UNIT AND NOX SENSORS MUST BE DISCONNECTED!

Steyr

BOSCH EDC17CV41 - SWITCH SOLUTION.

Tigercat

BOSCH EDC7UC31 - SWITCH SOLUTION.

BOSCH EDC17CV41 - COMBINATED SOLUTION

Toyota

DELPHI DCM6.2 - COMBINED SOLUTION

VAG

BOSCH EDC17_C46 - SWITCH SOLUTION. NOX SENSORS CAN BE DISCONNECTED.

BOSCH EDC17_C54 - SWITCH SOLUTION. NOX SENSORS CAN BE DISCONNECTED.

BOSCH EDC17C64 - SWITCH SOLUTION. NOX SENSORS CAN BE DISCONNECTED.

BOSCH EDC17C74 - SWITCH SOLUTION. NOX SENSORS CAN BE DISCONNECTED.

BOSCH EDC17CP74 - SWITCH SOLUTION.

BOSCH EDC17_CP14 - SWITCH SOLUTION.

BOSCH EDC17_CP20 - SWITCH SOLUTION. NOX SENSORS CAN BE DISCONNECTED.

BOSCH EDC17_CP24 - SWITCH SOLUTION. NOX SENSORS CAN BE DISCONNECTED.

BOSCH EDC17_CP44 - SWITCH SOLUTION. NOX SENSORS CAN BE DISCONNECTED.

BOSCH EDC17_CP54

BOSCH MD1_CP014 - *IMPORTANT* ADBLUE UNIT AND PUMP MUST BE DISCONNECTED!

DELPHI DCM6.2 - COMBINATED SOLUTION. ADBLUE UNIT AND PUMP MUST BE DISCONNECTED.

Valtra

BOSCH EDC17CV41 - SWITCH SOLUTION. ADBLUE UNIT MUST BE

DISCONNECTED. NOx SENSORS CAN BE DISCONNECTED!

BOSCH EDC17CV44 - SWITCH SOLUTION. ADBLUE UNIT MUST BE DISCONNECTED. NOx SENSORS CAN BE DISCONNECTED!

BOSCH EDC17CV54 - SWITCH SOLUTION. ADBLUE UNIT MUST BE DISCONNECTED. NOx SENSORS CAN BE DISCONNECTED!

Volkswagen Trucks

CUMMINS CM2150E - COMBINATED SOLUTION. REMOVE SCR FUSES!

Volvo Trucks

TRW EMS2 EU5 - COMBINATED SOLUTION. SCR FUSE OR SCR INJECTION MUST BE DISCONNECTED.

HOT Start Fix Module（热启动修复）

HONDA

BOSCH EDC16C31

VAG

BOSCH EDC15P

BOSCH EDC15V

BOSCH EDC16U1

BOSCH EDC16U31

BOSCH EDC16U34

BOSCH MD1CP004

BOSCH MD1CP014

SIEMENS PPD1.2

SIEMENS PPD1.3

SIEMENS PPD1.5

IMMO Removal Module (防盗关闭)

BMW

BOSCH EDC17_CP02

BOSCH EDC17_C06

BOSCH EDC17_CP09

BOSCH EDC17_C41

BOSCH EDC17_CP45

BOSCH EDC17_CP49

BOSCH EDC17_C50

BOSCH EDC17_C56

BOSCH MED17.1.1

BOSCH MEVD17.2

BOSCH MEVD17.2.5

BOSCH MEVD17.2.6

BOSCH MEVD17.2.8

BOSCH MEVD17.2.9

BOSCH MEVD17.2.G

BOSCH MEVD17.2.H

Citroen

BOSCH EDC17_C10

BOSCH EDC17_C60

SIEMENS SID807. MUST INPUT 4 DIGIT PIN CODE IN MODIFIED
AREA!

Lada

BOSCH ME17.9.7

Mini

BOSCH MEVD17.2.X

Opel

BOSCH EDC17_C18

BOSCH EDC17_C19

BOSCH EDC17_C59

Peugeot

BOSCH EDC17_C10

BOSCH EDC17_C60

SIEMENS SID807. MUST INPUT 4 DIGIT PIN CODE IN MODIFIED AREA!

Renault

SAGEM S3000 (Virgin file solution)

Suzuki

BOSCH ME17.8

VAG

BOSCH EDC17_U01

BOSCH EDC17_CP04

BOSCH EDC17_CP14

BOSCH EDC17CP20

BOSCH EDC17_CP24

BOSCH EDC17_C46

BOSCH EDC17_C54

BOSCH EDC17_CP54

BOSCH EDC17C64

BOSCH EDC17C74

MED17.1. FLASH AND EEPROM MUST BE PROCESSED.

MED17.1.1

MED17.5. PROCESSOR AND EEPROM MUST BE PROCESSED.

MED17.5.2

MED17.5.5

MED17.5.6

Volvo

BOSCH EDC17_CP22

Readiness Calibration Module (排放监控关闭)

BMW

BOSCH EDC17_CP02

BOSCH EDC17_CP09

BOSCH EDC17_CP49

BOSCH EDC17_C41

BOSCH EDC17_C50

BOSCH EDC17_C56

BOSCH MG1CS003

Citroen

BOSCH MD1CS003

BOSCH MED17.4.2

Ford

BOSCH MED17

Iveco

BOSCH EDC17_C49

Mercedes

BOSCH EDC16CP31

BOSCH EDC17CP01

BOSCH EDC17CP10

BOSCH EDC17CP46

BOSCH EDC17CP57

BOSCH MD1CP001

BOSCH MED17.1

BOSCH MED17.1.1

BOSCH MED17.2.1

BOSCH MED17.2.2

BOSCH MED17.7.1

BOSCH MED17.7.4

BOSCH MED17.7.5

Peugeot

BOSCH MD1CS003

BOSCH MED17.4.2

Porsche

BOSCH EDC17_CP44

Renault

BOSCH EDC17_C84

VAG

BOSCH EDC17_CP14

BOSCH EDC17_CP20

BOSCH EDC17_CP24

BOSCH EDC17_CP44

BOSCH EDC17_C46

BOSCH EDC17_C54

BOSCH EDC17C64

BOSCH EDC17C74

BOSCH MED17.1

BOSCH MED17.1.1

BOSCH MED17.1.6

BOSCH MED17.1.21

BOSCH MED17.5

BOSCH MED17.5.20

BOSCH MED17.5.21

BOSCH MED17.5.24

BOSCH MED17.5.25

BOSCH MED17.5.26

BOSCH MED17.6

SIEMENS PCR2.1

Flaps / Swirl Removal Module (襟翼/涡流关闭)

Alfa Romeo

BOSCH EDC16C39

BOSCH EDC17C49. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17C69. ACTUATOR PLUG MUST BE DISCONNECTED!

BMW

BOSCH EDC16C31. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC16C35. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC16CP31. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_C06. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_C41. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_C50. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_C56. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_C76. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_CP02. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_CP09. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_CP45. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_CP49. ACTUATOR PLUG MUST BE DISCONNECTED!

Chrysler

BOSCH EDC16CP31. FULL READ REQUIRED. ACTUATOR PLUG MUST BE DISCONNECTED!

Chevrolet

DELCO E83 ACTUATOR PLUG MUST BE DISCONNECTED!

DELCO E87 ACTUATOR PLUG MUST BE DISCONNECTED!

DELCO E98 ACTUATOR PLUG MUST BE DISCONNECTED!

Dacia

BOSCH EDC17_C42.

FCA (Alfa/Fiat/Lancia)

BOSCH EDC16C39

Fiat

BOSCH EDC16C39. BDM READ REQUIRED.

BOSCH EDC17C49. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17C69. ACTUATOR PLUG MUST BE DISCONNECTED!

Honda

BOSCH EDC16C31. ACTUATOR PLUG MUST BE DISCONNECTED!

Hyundai

BOSCH EDC16C39. ACTUATOR PLUG MUST BE DISCONNECTED! BDM

READ REQUIRED.

BOSCH EDC17_C08

BOSCH EDC17_CP14

BOSCH EDC17_C53

BOSCH EDC17_C57

Isuzu

TRANSTRON. ACTUATOR PLUG MUST BE DISCONNECTED!

Jeep

BOSCH EDC17C49. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17C69. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_C79. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_CP27. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC16CP31

Kia

BOSCH EDC16C39. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_C08

BOSCH EDC17_CP14

BOSCH EDC17_C53

BOSCH EDC17_C57

Lancia

BOSCH EDC16C39 BDM READ REQUIRED.

Lexus

DENSO. ACTUATOR PLUG MUST BE DISCONNECTED!

Mercedes

BOSCH EDC15C6. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC16C2. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC16C31. ACTUATOR PLUG MUST BE DISCONNECTED! BDM
READ REQUIRED.

BOSCH EDC16C32 BDM READ REQUIRED.

BOSCH EDC16CP31. FULL READ REQUIRED. BDM READ REQUIRED.

BOSCH EDC16CP36. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17CP01. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17CP10. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17CP46. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17CP57. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17C66. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH MD1CP001

DELPHI CRD3 - ACTUATOR PLUG MUST BE DISCONNECTED!

Nissan

BOSCH EDC17_C42.

Opel

BOSCH EDC16C9. ACTUATOR PLUG MUST BE DISCONNECTED! BDM
READ REQUIRED.

BOSCH EDC16C39 ACTUATOR PLUG MUST BE DISCONNECTED! BDM
READ REQUIRED.

BOSCH EDC17_C18. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_C19 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH EDC17_C42 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH EDC17_C59. ACTUATOR PLUG MUST BE DISCONNECTED!

DENSO. ACTUATOR PLUG MUST BE DISCONNECTED!

DELPHI DCM3.7

DELCO E83 ACTUATOR PLUG MUST BE DISCONNECTED!

DELCO E87 ACTUATOR PLUG MUST BE DISCONNECTED!

DELCO E98 ACTUATOR PLUG MUST BE DISCONNECTED!

Porsche

BOSCH EDC17_CP14. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_CP44. ACTUATOR PLUG MUST BE DISCONNECTED!

Renault

BOSCH EDC16C3. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC16CP33

BOSCH EDC17_C42

Smart

BOSCH EDC16C31 BDM READ REQUIRED.

Suzuki

BOSCH EDC16C3. ACTUATOR PLUG MUST BE DISCONNECTED!

Toyota

DENSO. ACTUATOR PLUG MUST BE DISCONNECTED!

VAG

BOSCH EDC15V. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC16C2. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC16C4. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC16U1. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC16U31. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC16U34. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC16CP34. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_C46. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_C54. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17C64. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17C74. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_CP04. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_CP14. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_CP20. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_CP24. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_CP44. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_CP54. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17CP74. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_U01. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_U05. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH ME7.5.

BOSCH MED9.1. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH MED9.1.1. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH MED17.1. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH MED17.5. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH MED17.5.1. ACTUATOR PLUG MUST BE DISCONNECTED!

DELPHI DCM3.7. ACTUATOR PLUG MUST BE DISCONNECTED!

SIEMENS PPD1.X. ACTUATOR PLUG MUST BE DISCONNECTED!

Volvo

BOSCH EDC16C31. ACTUATOR PLUG MUST BE DISCONNECTED!

DENSO VEA - ACTUATOR PLUG MUST BE DISCONNECTED!

TVA Removal Module（柴油车节气门执行器关闭）

Alfa Romeo

BOSCH EDC16C39. ACTUATOR PLUG MUST BE DISCONNECTED!

BMW

BOSCH EDC16C31. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC16C35. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC16CP31. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_C06. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_C41. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_C50. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_C56. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_C76. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_CP02. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_CP09. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_CP45. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH MEVD17.2. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH MEVD17.2.5. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH MEVD17.2.6. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH MEVD17.2.8. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH MEVD17.2.9. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH MEVD17.2.G. ACTUATOR PLUG MUST BE DISCONNECTED!

SIEMENS MSD85

Caterpillar

CAT ADEM5.

Chevrolet

DELCO E83 ACTUATOR PLUG MUST BE DISCONNECTED!

DELCO E87 ACTUATOR PLUG MUST BE DISCONNECTED!

DELCO E98 ACTUATOR PLUG MUST BE DISCONNECTED!

Citroen

BOSCH EDC16C39. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC16CP39. ACTUATOR PLUG MUST BE DISCONNECTED!

SIEMENS SID807.

Dacia

BOSCH EDC17_C42. ACTUATOR PLUG MUST BE DISCONNECTED!

Dodge

BOSCH EDC17_C79

FCA (Alfa/Fiat/Lancia)

BOSCH EDC16C39

BOSCH ME7.9.10

Fiat

BOSCH EDC16C39. ACTUATOR PLUG MUST BE DISCONNECTED! BDM

READ REQUIRED.

MARELLI MJ8F. ACTUATOR PLUG MUST BE DISCONNECTED!

Ford

BOSCH EDC17_C10.

BOSCH EDC17C70. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_CP05. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_CP42. ACTUATOR PLUG MUST BE DISCONNECTED!

SIEMENS SID211

SIEMENS SID802. ACTUATOR PLUG MUST BE DISCONNECTED!

SIEMENS SID804. ACTUATOR PLUG MUST BE DISCONNECTED!

Honda

BOSCH EDC17C58

Hyundai

BOSCH EDC16C39. ACTUATOR PLUG MUST BE DISCONNECTED!

Iveco

BOSCH EDC15C2. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC16C39. ACTUATOR PLUG MUST BE DISCONNECTED! BDM

READ REQUIRED.

Jeep

BOSCH EDC16C39. ACTUATOR PLUG MUST BE DISCONNECTED!

Kia

BOSCH EDC16C39. ACTUATOR PLUG MUST BE DISCONNECTED!

Mazda

DENSO R2AX - *IMPORTANT* ACTUATOR PLUG MUST BE DISCONNECTED!

Mercedes

BOSCH EDC16C31. BDM READ REQUIRED. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC16C32. ACTUATOR PLUG MUST BE DISCONNECTED! BDM READ REQUIRED.

BOSCH EDC16CP31. BDM READ REQUIRED. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC16CP36. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_C42. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17C43. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17C66. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17CP01. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17CP10. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17CP46. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17CP57. ACTUATOR PLUG MUST BE DISCONNECTED!

DELPHI CRD2. ACTUATOR PLUG MUST BE DISCONNECTED!

DELPHI CRD3. ACTUATOR PLUG MUST BE DISCONNECTED!

DELPHI DCM3.2. ACTUATOR PLUG MUST BE DISCONNECTED!

Mini

BOSCH EDC16C35. ACTUATOR PLUG MUST BE DISCONNECTED!

Mitsubishi

BOSCH EDC16C31. ACTUATOR PLUG MUST BE DISCONNECTED!

DENSO. ACTUATOR PLUG MUST BE DISCONNECTED!

Nissan

BOSCH EDC17_C42. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_C45

SIEMENS SID305. ACTUATOR PLUG MUST BE DISCONNECTED!

Opel

BOSCH EDC16CP33. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_C11. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_C18. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_C19. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_C42. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_C59. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_C84. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_CP47. ACTUATOR PLUG MUST BE DISCONNECTED!

DELCO E83 ACTUATOR PLUG MUST BE DISCONNECTED!

DELCO E87 ACTUATOR PLUG MUST BE DISCONNECTED!

DELCO E98 ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH PSG16

Peugeot

BOSCH EDC16C39. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC16CP39. ACTUATOR PLUG MUST BE DISCONNECTED!

SIEMENS SID807.

Renault

BOSCH EDC17_C11

BOSCH EDC17_C42. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC16C36. ACTUATOR PLUG MUST BE DISCONNECTED!

Saab

BOSCH PSG16

Suzuki

BOSCH EDC15C2. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC16C3. ACTUATOR PLUG MUST BE DISCONNECTED!

Toyota

DENSO

VAG

BOSCH EDC15P. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC16C4. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC16U1. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC16U31. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC16CP34. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_C46. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_C54. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17C64. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17C74. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_CP04. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_CP14. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_CP20. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_CP24. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_CP44. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_CP54. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17CP74. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_U01. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC17_U05. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH MD1_CP004

SIEMENS PCR2.1. ACTUATOR PLUG MUST BE DISCONNECTED!

Volvo

BOSCH EDC16C31. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC16C34. ACTUATOR PLUG MUST BE DISCONNECTED!

Sport Displays Calibration Module (宝马运动仪表)

BMW

BOSCH EDC17_C41

BOSCH EDC17_CP45

BOSCH EDC17_CP49

BOSCH EDC17_C50

BOSCH EDC17_C56

BOSCH MEVD17.2.3

BOSCH MEVD17.2.4

BOSCH MEVD17.2.6

BOSCH MEVD17.2.G

BOSCH MD1CP002

BOSCH MG1CS003

BOSCH MG1CS201

Mini

BOSCH EDC17_C41

BOSCH EDC17_C50

BOSCH EDC17_C56

BOSCH MEVD17.2.3

Cold Start Noise Reduction Module (冷启动关闭)

BMW

SIEMENS MSD8X. N54 ENGINES ONLY!

BOSCH MEVD17.2.3

Kickdown Deactivation Module（关闭降档功能）

BMW

SIEMENS MSD8X. N54 ENGINES ONLY!

StartStop Disable Module（关闭启停）

BMW

BOSCH EDC17_C06

BOSCH EDC17_C41

BOSCH EDC17_C50

BOSCH EDC17_C56

BOSCH EDC17_CP02

BOSCH EDC17_CP09

BOSCH EDC17_CP45

BOSCH MEVD17.2.2

BOSCH MEVD17.2.5

BOSCH MEVD17.2.6

BOSCH MEVD17.2.8

BOSCH MEVD17.2.9

BOSCH MEVD17.2.G

BOSCH MED17

Fiat

MARELLI MJ8X

Land Rover

BOSCH EDC17CP55 - *IMPORTANT* SWITCH SOLUTION!

Mazda

DENSO. (SKY ACTIVE ONLY)

Mercedes

BOSCH EDC17CP46

Mini

BOSCH EDC17_C41

Opel

MARELLI MJ8X

BOSCH EDC17_C59

Porsche

BOSCH EDC17_CP44

SIEMENS SDI10

Suzuki

MARELLI MJ8X

VAG

BOSCH EDC17_CP44

BOSCH EDC17_CP54

BOSCH EDC17_C46

BOSCH EDC17_C54

BOSCH EDC17C64

BOSCH EDC17C74

SIEMENS PCR2.1

Volvo

BOSCH EDC16C34

MAF Removal Module (MAF 传感器关闭)

Alfa Romeo

BOSCH EDC16C39.

BOSCH EDC17C49

BMW

BOSCH EDC16C31. MAF MUST BE DISCONNECTED.

Citroen

SIEMENS SID806. MAF MUST BE DISCONNECTED.

Chevrolet

BOSCH EDC16C39

Dacia

SIEMENS SID305. MAF MUST BE DISCONNECTED.

Dodge

BOSCH EDC16U31

FCA (Alfa/Fiat/Lancia)

BOSCH EDC16C39

Fiat

BOSCH EDC16C39. MAF MUST BE DISCONNECTED.

BOSCH EDC17C49

MARELLI MJ8F - MAF MUST BE DISCONNECTED.

Ford

BOSCH EDC16C34. MAF MUST BE DISCONNECTED.

BOSCH ME9*

BOSCH EDC17_C10 - *IMPORTANT* ACTUATOR PLUG MUST BE

DISCONNECTED!

BOSCH EDC17_CP05 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH EDC17_CP42 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH EDC17_CP65 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH EDC17C70 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

Infiniti

DELPHI CRD3. MAF MUST BE DISCONNECTED.

Lancia

BOSCH EDC16C39.

BOSCH EDC17C49

Land Rover

BOSCH EDC17_CP11 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH EDC17_CP42 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

BOSCH EDC17_CP55 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

Mercedes

EDC15C0

EDC15C6 - *IMPORTANT* ACTUATOR PLUG MUST BE
DISCONNECTED!

DELPHI CRD3. MAF MUST BE DISCONNECTED.

Mini

BOSCH EDC17_C41. MAF MUST BE DISCONNECTED.

Mitsubishi

BOSCH EDC16U31

Nissan

SIEMENS SID301. MAF MUST BE DISCONNECTED.

SIEMENS SID305. MAF MUST BE DISCONNECTED.

Opel

BOSCH EDC15M

Peugeot

SIEMENS SID806. MAF MUST BE DISCONNECTED.

Renault

BOSCH EDC15C3. MAF MUST BE DISCONNECTED.

SIEMENS SID305. MAF MUST BE DISCONNECTED.

VAG

BOSCH EDC15P

BOSCH EDC15V

BOSCH EDC15VM

BOSCH EDC16CP34. ACTUATOR PLUG MUST BE DISCONNECTED!

BOSCH EDC16U1

BOSCH EDC16U31

BOSCH EDC16U34

BOSCH EDC17_CP14

BOSCH MD1_CP004

BOSCH MD1_CP014

SIEMENS PCR2.1 - ACTUATOR PLUG MUST BE DISCONNECTED!

Speed Limiter Removal Module（限速关闭）

BMW

BOSCH EDC16C31

BOSCH EDC16C35

BOSCH EDC16CP35

BOSCH EDC17_C41

BOSCH EDC17_C50

BOSCH EDC17_C56

BOSCH EDC17_CP02

BOSCH EDC17_CP09

BOSCH EDC17_CP45

BOSCH EDC17_CP49

BOSCH MG1CS003

BOSCH MG1CS201

BOSCH ME7

BOSCH ME9

BOSCH MED17.1.1

BOSCH MEVD17.2 (H)

BOSCH MEVD17.2.5

BOSCH MEVD17.2.6

BOSCH MEVD17.2.8

BOSCH MEVD17.2.9

BOSCH MEVD17.2.G

SIEMENS MSS52

SIEMENS MSS54

SIEMENS MSD80

SIEMENS MSD81

SIEMENS MSD85

SIEMENS MSV70

Bonetti

BOSCH EDC17CP52

CAN-AM

BOSCH MED17.8.5

BOSCH ME17.8.5

Citroen

BOSCH EDC16C34

BOSCH EDC16C39

BOSCH EDC17C10. BETA.

BOSCH EDC17_C60. REMOVES 150 KMH LIMITER ONLY.

BOSCH EDC17CP52

BOSCH MED17.4.2 (4 MB READS ONLY)

DELPHI DCM3.5

SIEMENS SID206

SIEMENS SID807

DAF

DELPHI DMCI

MOTOROLA CM850

Dodge

BOSCH EDC17_C79

Fiat

BOSCH EDC16C8

BOSCH EDC16C39

BOSCH EDC17_CP52

BOSCH EDC17CP52

Ford

SIEMENS SID202

SIEMENS SID206

SIEMENS SID208

SIEMENS SID209

SIEMENS SID211

SIEMENS SID807

Visteon DCU102

Visteon DCU106

Visteon EECV

Visteon EECVi

BOSCH EDC17C70

Honda

BOSCH EDC17_CP50

Hyundai

BOSCH EDC17_C08

BOSCH EDC17_C53

BOSCH EDC17_C57

BOSCH EDC17_CP14

Isuzu

BOSCH EDC17CV41

TRANSTRON

Iveco

BOSCH EDC7U31

BOSCH EDC16C8

BOSCH EDC16C39

BOSCH EDC17C49

BOSCH EDC17CV41

BOSCH EDC17CP52

Jaguar

BOSCH EDC17CP55

Jinbei

BOSCH EDC16C39

John Deere

PHOENIX L14. BETA.

Kia

BOSCH EDC17_C08

BOSCH EDC17_C57

BOSCH EDC17_CP14

KEFICO CPEGD2

Land Rover

BOSCH EDC16CP39

BOSCH EDC17CP55

BOSCH MEDC17.9

SIEMENS SID208

VISTEON DCU102

VISTEON DCU106

LDV

BOSCH EDC16C39

VISTEON EECV

Lexus

DENSO

Mazda

BOSCH EDC16C31

BOSCH EDC16C7

Mercedes

BOSCH EDC15C6 (EEPROM)

BOSCH EDC16C31

BOSCH EDC16CP31

BOSCH EDC16CP36

BOSCH EDC17C66

BOSCH EDC17CP10

BOSCH EDC17CP46

BOSCH ME2.0

BOSCH ME2.7

BOSCH ME2.7.1

BOSCH ME2.8

BOSCH ME2.8.1

BOSCH ME9.7

BOSCH MED17.7.1

BOSCH MED17.7.2

BOSCH MED17.7.3

DELPHI CRD2

DELPHI CRD3.x

SIEMENS SID310

Mini

BOSCH MEVD17.2.3

Mitsubishi

BOSCH EDC16C31

BOSCH EDC16U31

BOSCH EDC17C49

BOSCH EDC17CP15

BOSCH MED17.7

New Holland

BOSCH EDC16C41

Nissan

BOSCH EDC16C41

BOSCH EDC16CP33

BOSCH EDC17_C42

SIEMENS SID309

Opel

BOSCH EDC15C3

BOSCH EDC16C36

BOSCH EDC16C39

BOSCH EDC16CP33

BOSCH EDC17_C11

BOSCH EDC17_C42

Peugeot

BOSCH EDC16C34

BOSCH EDC16C39

BOSCH EDC17C10. BETA.

BOSCH EDC17_C60. REMOVES 150 KMH LIMITER ONLY.

BOSCH EDC17CP52

BOSCH MED17.4.2 (4 MB READS ONLY)

DELPHI DCM3.5

SIEMENS SID206

SIEMENS SID807

Polaris

BOSCH ME17.8.7

BOSCH ME17.9.74

Porsche

BOSCH EDC17_CP14

BOSCH EDC17_CP44

SIEMENS SDI4 (USA spec only, 210km/h)

Renault

BOSCH EDC15C3

BOSCH EDC16C3

BOSCH EDC16C36

BOSCH EDC16C41

BOSCH EDC16CP33

BOSCH EDC17_C11

BOSCH EDC17_C42

BOSCH EDC17_CP19

BOSCH EDC17_CP58

SIEMENS SID305

SIEMENS SID307

SIEMENS SID309

SIEMENS SID310

Smart

BOSCH ME7.7.0

BOSCH ME17.9.20

BOSCH EDC16C31

SeaDoo

BOSCH MED17

Suzuki

BOSCH EDC16C3

Toyota

DENSO

VAG

BOSCH EDC15P (EEPROM REQUIRED)

BOSCH EDC15VM+ (EEPROM REQUIRED)

BOSCH EDC16U1

BOSCH EDC16U31

BOSCH EDC16U34

BOSCH EDC16CP34

BOSCH EDC17_C46

BOSCH EDC17_C54

BOSCH EDC17_CP04

BOSCH EDC17_CP14

BOSCH EDC17_CP20

BOSCH EDC17_CP24

BOSCH EDC17_CP44

BOSCH EDC17_U01

BOSCH EDC17C64

BOSCH EDC17C74

BOSCH ME7.1.1

BOSCH ME7.5

BOSCH MED9.1

BOSCH MED9.1.1

BOSCH MED9.1.2

BOSCH MED17.1

BOSCH MED17.1.1

BOSCH MED17.5

BOSCH MED17.5.2

BOSCH MED17.5.6

DELPHI DCM6.2 (CRAFTER AND TRANSPORTER HAVE THEIR SLs
LOCATED IN EEPROM, SO ONLY MANUFACTURER TOOL WORKS)

SIEMENS PCR2.1

SIEMENS SIMOS 8.5

SIEMENS SIMOS 10.x

SIEMENS SIMOS 12

SIEMENS SIMOS 16

SIEMENS SIMOS 18

Volvo

BOSCH EDC16C31

BOSCH EDC17_CP22

BOSCH EDC17_CP48

SIEMENS SID807

Lambda/O2 Removal Module (氧传感器关闭)

Alfa Romeo

BOSCH MED7.1

BOSCH MED7.6.1

BOSCH ME7.3.1

BOSCH ME7.9.10

BOSCH MED17.3.1

BOSCH MED17.3.3

MARELLI MM8

Bentley

BOSCH ME7.1.1

BMW

BOSCH ME7

BOSCH ME9.2

BOSCH ME17.2.1

BOSCH MEV9.4.6

BOSCH MEV17.4.6

BOSCH MEVD17.2.2 - *IMPORTANT* PROBE MUST BE
DISCONNECTED!

BOSCH MEVD17.2.3 - *IMPORTANT* PROBE MUST BE
DISCONNECTED!

BOSCH MEVD17.2.4

BOSCH MEVD17.2.6

BOSCH MEVD17.2.8

BOSCH MEVD17.2.G

BOSCH MEVD17.4.6

BOSCH MG1CS003

BOSCH MG1CS024

BOSCH MG1CS201

SIEMENS MS42

SIEMENS MS43

SIEMENS MS45

SIEMENS MSS52

SIEMENS MSS54

SIEMENS MSS60 (M3)

SIEMENS MSS70

SIEMENS MSD80. DISCONNECT NOx PLUG.

SIEMENS MSD81. DISCONNECT NOx PLUG.

SIEMENS MSV70

SIEMENS MSV80

Chevrolet

BOSCH ME7.9.9

BOSCH MED9.6.2

BOSCH MEVD17.4.2

DELCO E37 *IMPORTANT* PROBE MUST BE DISCONNECTED!

DELCO E38 *IMPORTANT* PROBE MUST BE DISCONNECTED!

DELCO E7x *IMPORTANT* PROBE MUST BE DISCONNECTED!

DELCO E78 *IMPORTANT* PROBE MUST BE DISCONNECTED!

DELCO E80 *IMPORTANT* PROBE MUST BE DISCONNECTED!

DELCO E83 *IMPORTANT* PROBE MUST BE DISCONNECTED!

DELCO E8x *IMPORTANT* PROBE MUST BE DISCONNECTED!

DELCO E87 *IMPORTANT* PROBE MUST BE DISCONNECTED!

DELCO E92 *IMPORTANT* PROBE MUST BE DISCONNECTED!

DELCO E98 *IMPORTANT* PROBE MUST BE DISCONNECTED!

MARELLI IAW48P2

SIEMENS SIMTEC76

Citroen

BOSCH M7.9.52

BOSCH ME7.4.4

BOSCH ME7.4.6

BOSCH ME7.4.9

BOSCH ME7.9.52

BOSCH MED17

BOSCH MED17.2.2

BOSCH MED17.4.2

BOSCH MEV17

BOSCH MEV17.4.2

BOSCH MEVD17.4.4

MARELLI IAW6LP (2.0 177 RC)

Dodge

CUMMINS CM21XX. *IMPORTANT* PROBE MUST BE
DISCONNECTED!

Ferrari

BOSCH MED9.6.1

BOSCH MED17.3.5

BOSCH ME7.3.2

Fiat

BOSCH MED7.6.1

BOSCH ME7.9.10

BOSCH ME17.3.0

BOSCH MED17.3.1

BOSCH MED17.3.3

MARELLI MM8

MARELLI IAW5AF

MARELLI MM9 - *IMPORTANT* PROBE MUST BE DISCONNECTED!

Ford

BOSCH ME9.0C

BOSCH MED17

SIEMENS EMS200

SIEMENS EMS2100

VISTEON EECVI (ST150 2.0)

VISTEON M799G

BOSCH MED17.2.2 - *IMPORTANT* PROBE MUST BE
DISCONNECTED!

Honda

BOSCH ME7.9.3

Hyundai

BOSCH ME17.9.11

SIEMENS SIM2K

SIEMENS SIMK41

Infiniti

HITACHI *BETA

Jaguar

DENSO. 512 KB FILES ONLY.

Jeep

MOTOROLA NGC4 - *IMPORTANT* PROBE PLUG MUST BE
DISCONNECTED!

Kia

BOSCH ME17.9.11

KEFICO CPEGD2.20.1 - *IMPORTANT* PROBE MUST BE
DISCONNECTED!

KEFICO CPEGD2.20.2 - *IMPORTANT* PROBE MUST BE

DISCONNECTED!

KEFICO CPEGD2.20.3 - *IMPORTANT* PROBE MUST BE

DISCONNECTED!

KEFICO CPEGD2.20.4 - *IMPORTANT* PROBE MUST BE

DISCONNECTED!

Land Rover

BOSCH ME7.2

DENSO (PETROL ONLY)

Lancia

BOSCH ME7.9.10

BOSCH MED17.3.1

BOSCH MED17.3.3

Maserati

BOSCH ME7.3.2

BOSCH ME7.9.3

Mazda

HITACHI MEC33

VISTEON M799G

Mercedes

BOSCH ME2.8.1

BOSCH ME9.7

BOSCH MED17.1

BOSCH MED17.1.1

BOSCH MEVD17.2.1

BOSCH MED17.2.2

BOSCH MED17.7.1

BOSCH MED17.7.4

BOSCH MED17.7.5

Mini

BOSCH ME9.2

BOSCH MEVD17.2.2

BOSCH MEVD17.2.3 - *IMPORTANT* PROBE PLUG MUST BE
DISCONNECTED!

BOSCH MEV17.2.2

SIEMENS EMS

Mini

BOSCH MED17.2

Mitsubishi

DENSO (PETROL ONLY)

Nissan

HITACHI

Opel

BOSCH ME1.5.5

BOSCH ME7.6.x

BOSCH ME9.6

BOSCH ME9.6.1

BOSCH MED9.6.2

DELCO E37 *IMPORTANT* PROBE MUST BE DISCONNECTED!

DELCO E38 *IMPORTANT* PROBE MUST BE DISCONNECTED!

DELCO E39 (1.4T, 2.0T) *IMPORTANT* PROBE MUST BE
DISCONNECTED!

DELCO E7x *IMPORTANT* PROBE MUST BE DISCONNECTED!

DELCO E78 *IMPORTANT* PROBE MUST BE DISCONNECTED!

DELCO E80 *IMPORTANT* PROBE MUST BE DISCONNECTED!

DELCO E83 *IMPORTANT* PROBE MUST BE DISCONNECTED!

DELCO E8x *IMPORTANT* PROBE MUST BE DISCONNECTED!

DELCO E92 *IMPORTANT* PROBE MUST BE DISCONNECTED!

DELCO MT35

SIEMENS SIMTEC 71

SIEMENS SIMTEC 76

Peugeot

BOSCH M7.9.52

BOSCH ME7.4.4

BOSCH ME7.4.6

BOSCH ME7.4.9

BOSCH ME7.9.52

BOSCH MED17

BOSCH MED17.2.2

BOSCH MED17.4.2

BOSCH MEV17

BOSCH MEV17.4.2

BOSCH MEVD17.4.4

MARELLI IAW48P2

MARELLI IAW6LP (2.0 177 RC)

Porsche

BOSCH ME7.1.1

BOSCH ME7.2

BOSCH ME7.8.x

BOSCH MED9.1

BOSCH MED9.1.1 - *IMPORTANT* PROBE MUST BE DISCONNECTED!

BOSCH MG1CS002 - *IMPORTANT* PROBE MUST BE
DISCONNECTED!

BOSCH MED17.1.6

SIEMENS SDI3

SIEMENS SDI7 - *IMPORTANT* PROBE PLUG MUST BE
DISCONNECTED!

Renault

SAGEM S3000

SIEMENS EMS31x0

SIEMENS EMS3110

SIEMENS EMS3132

Smart

BOSCH ME7.7.0

Subaru

DENSO (MY 200x)

Suzuki

BOSCH ME9.1

BOSCH ME9.6.1

BOSCH MED17.9.63 - *IMPORTANT* PROBE MUST BE
DISCONNECTED!

Toyota

BOSCH M7.9.4

BOSCH M7.9.5

BOSCH ME7.9.52

DENSO

VAG

BOSCH EDC17_CP14

BOSCH MED9

BOSCH MED9.1

BOSCH MED9.5.10

BOSCH ME7.1.1

BOSCH ME7.5

BOSCH ME17.5.26

BOSCH MED7.1.1

BOSCH MED17

BOSCH MED17.1.6

BOSCH MED17.5

BOSCH MED17.5.21

BOSCH MED17.5.5

MARELLI IAW4MV

SIEMENS SIMOS 3.2

SIEMENS SIMOS 6.2

SIEMENS SIMOS 7.1. FULL READ REQUIRED.

SIEMENS SIMOS 8

SIEMENS SIMOS 8.3

SIEMENS SIMOS 8.5

SIEMENS SIMOS 9.1

SIEMENS SIMOS 12

SIEMENS SIMOS 18

Volvo

BOSCH ME9

DENSO VEA

Launch Control Module (弹射启动)

BMW

BOSCH EDC16C31 *BETA

BOSCH EDC16C35 *BETA

BOSCH EDC16CP35 *BETA

BOSCH EDC17_C06 *BETA

BOSCH EDC17_C41 *BETA

BOSCH EDC17_C50 *BETA

BOSCH EDC17_C56 *BETA

BOSCH EDC17_C76 *BETA

BOSCH EDC17_CP02 *BETA

BOSCH EDC17_CP09 *BETA

BOSCH EDC17_CP45 *BETA

BOSCH EDC17_CP49 *BETA

Fiat

MARELLI MJ8x. BETA.

Ford

BOSCH EDC15P

VISTEON DCU102

KIA

KEFICO CPEGD2

Opel

MARELLI MJ8x. BETA.

Renault

BOSCH EMS31x0

Suzuki

MARELLI MJ8x. BETA.

VAG

BOSCH EDC15P

BOSCH EDC15V (FOR 512 KB ONLY)

TEMIC DSG DQ250

SIEMENS PPD1.x

OBD Reading Protection (OBD 读写保护)

BMW - Bosch EDC17

VAG Group - Bosch EDC16/EDC17/ME7/MED9

BOSCH EDC16U31/U34

Boost Sensor Calibration Module (增压压力传感器修正)

BMW

BOSCH EDC15C4

BOSCH EDC16C31

BOSCH EDC16C35

BOSCH EDC16CP31

SIEMENS MSD8X. N54 ENGINE ONLY.

Citroen

BOSCH EDC16C34. 607 2.2 SENSOR CALIBRATION FOR 1.6hdi

PART:9649396580 CHOOSE: BOOSTSENSCAL35.

BOSCH EDC16CP34

Fiat

BOSCH EDC16C9

BOSCH EDC16C39

Ford

BOSCH EDC16C34

Jeep

BOSCH EDC16C31

BOSCH EDC16CP31

KIA

KEFICO CPEGD2

Mazda

BOSCH EDC16C34

Mercedes

BOSCH EDC16C31

BOSCH EDC16CP31

Opel

BOSCH EDC16C9

BOSCH EDC16C39

Peugeot

BOSCH EDC16C34. 607 2.2 SENSOR CALIBRATION FOR 1.6hdi
PART:9649396580 CHOOSE: BOOSTSENSCAL35.

BOSCH EDC16CP34

Saab

BOSCH EDC16C9

BOSCH EDC16C39

VAG

BOSCH EDC15P

BOSCH EDC16U1

BOSCH EDC16U31

BOSCH EDC16U34

BOSCH EDC17_CP14

SIEMENS SIMOS 12

